

PROPELLER SHAFT & DIFFERENTIAL CARRIER

SECTION PD

CONTENTS

PREPARATION	PD- 2
PROPELLER SHAFT	PD- 5

Model R200V

FINAL DRIVE	PD- 8
DISASSEMBLY	PD-11
INSPECTION	PD-15
ADJUSTMENT	PD-16
ASSEMBLY	PD-24

Model H190A









FINAL DRIVE	PD-28
DISASSEMBLY	PD-29
INSPECTION	PD-33
LIMITED SLIP DIFFERENTIAL	PD-34
ADJUSTMENT	PD-40
ASSEMBLY	PD-47
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	PD-52

PD

PREPARATION








SPECIAL SERVICE TOOLS

*: Special tool or a commercial equivalent

Tool number Tool name	Description	Unit application	
		R200V	H190A
ST38060002* Drive pinion flange wrench	 a: 152 mm (5.98 in)	Removing and installing propeller shaft lock nut, and drive pinion lock nut.	X X
KV38100800 Differential attachment	 a: 152 mm (5.98 in)	Mounting final drive (To use, make a new hole.)	X —
ST06310000 Differential attachment		Mounting final drive	— X
ST3090S000* Drive pinion rear inner race puller set ① ST30031000 Puller ② ST30901000 Base		Removing and installing drive pinion rear cone a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35 mm (1.38 in) dia.	X X
ST3306S001 Differential side bearing puller set ① ST33051001* Body ② ST33061000* Adapter		Removing and installing differential side bearing inner cone a: 28.5 mm (1.122 in) dia. b: 38.0 mm (1.50 in) dia.	X X
ST30611000* Drift		Installing pinion rear bearing outer race	X X
ST30613000* Drift		Installing pinion rear bearing outer race a: 71.5 mm (2.815 in) dia. b: 47.5 mm (1.870 in) dia.	X X
ST30701000* Drift		Installing pinion front bearing outer race a: 61.5 mm (2.421 in) dia. b: 41.0 mm (1.610 in) dia.	X —








PREPARATION

*: Special tool or a commercial equivalent

Tool number Tool name	Description	Unit application	
		R200V	H190A
KV38100200 Gear carrier side oil seal drift	Installing side oil seal 	X	—
KV38100500* Gear carrier front oil seal drift	Installing front oil seal a: 85 mm (3.35 in) dia. b: 60 mm (2.36 in) dia. 	X	—
KV381025S0* Oil seal fitting tool ① ST30720000 Drift bar ② KV38102510 Drift	Installing front oil seal a: 77 mm (3.03 in) dia. b: 55 mm (2.17 in) dia. c: 71 mm (2.80 in) dia. d: 65 mm (2.56 in) dia. 	—	X
KV38100300 Differential side bearing inner cone	Installing side bearing inner cone 	X	—
ST33230000* Diff. side bearing drift	Installing side bearing inner cone a: 51 mm (2.01 in) dia. b: 28.5 mm (1.122 in) dia. 	—	X
KV38100600* Side bearing spacer drift	Installing side bearing spacer a: 8 mm (0.31 in) b: 42.5 mm (1.673 in) 	X	X
ST30621000* Drift	Installing pinion rear bearing outer race a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia. 	—	X



PREPARATION

*: Special tool or a commercial equivalent

Tool number Tool name	Description	Unit application		
		R200V	H190A	
ST3127S000 Preload gauge ① GG91030000 Torque wrench ② HT62940000 Socket adapter ③ HT62900000 Socket adapter		Measuring pinion bearing pre-load and total preload	X	X
HT72400000 Slide hammer		Removing differential case assembly	X	—
KV381039S0 Drive pinion setting gauge ① KV38103910 Dummy shaft ② KV38100120 Height gauge ③ KV38100140 Stopper		Selecting pinion height adjusting washer	X	—
ST3194S000 Drive pinion setting gauge set ① ST31941000 Height gauge ② ST31942000 Dummy shaft		Selecting pinion height adjusting washer	—	X
ST31970000 Collar		Selecting pinion height adjusting washer	—	X
ST32501000 Weight block		Selecting side bearing adjusting shim	X	X
KV38101900 Master gauge [20.0 mm (0.787 in)]		Selecting side bearing adjusting shim	—	X

PROPELLER SHAFT

Propeller Shaft (Model 2S63A)



On-vehicle Service

PROPELLER SHAFT VIBRATION

If vibration is present at high speed, check mounting between propeller shaft and companion flange of rear differential.


Make sure alignment marks A and B are located as close to each other as possible.

If not, change mounting as described in "Installation".

APPEARANCE CHECKING


- Inspect propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.

PROPELLER SHAFT




Removal

- Draw out propeller shaft from transmission and plug up rear end of transmission rear extension housing.




Installation


If companion flange has been removed, put new alignment marks B and C on it before reassembling using the following procedure. (When final drive and propeller shaft are separated from each other or when either part is replaced with a new one, perform step 4.)



1. Erase original marks B and C from companion flange with suitable solvent.
2. Mark (B)
 - A. Measure companion flange vertical runout.
 - B. Determine the position where maximum runout is read on dial gauge. Put mark (shown by B in figure at left) on flange perimeter corresponding to maximum runout position.




3. Mark (C)
 - A. Measure companion flange surface runout.
 - B. Determine the position where maximum runout is read on dial gauge. Put mark (shown by C in figure at left) on flange perimeter corresponding to maximum runout position.




4. Position companion flange and propeller shaft so that alignment marks A and B are as close to each other as possible. Temporarily attach bolts and nuts.
5. While pressing down propeller shaft with alignment mark C facing upward, tighten the lower nut to specified torque.
6. Tighten remaining nuts to specified torque.

PROPELLER SHAFT




Inspection

- Inspect propeller shaft runout. If runout exceeds specifications, replace propeller shaft assembly.
Runout limit: 0.6 mm (0.024 in)



- Inspect journal axial play. If the play exceeds specifications, replace propeller shaft assembly.
Journal axial play: 0 mm (0 in)

FINAL DRIVE (Model R200V)



SPD136A






- | | | |
|---|----------------------------------|--|
| ① Gear carrier | ⑩ Side bearing | ⑲ Differential case |
| ② Companion flange | ⑪ Gasket | ⑳ Side gear thrust washer |
| ③ Front oil seal | ⑫ Drain plug | ㉑ Circular clip |
| ④ Pinion front bearing | ⑬ Rear cover | ㉒ Side gear (R.H.) |
| ⑤ Pinion bearing adjusting washer | ⑭ Filler plug | ㉓ Pinion mate thrust washer |
| ⑥ Pinion bearing adjusting spacer
(Solid spacer) | ⑮ Breather | ㉔ Pinion mate gear |
| ⑦ Side oil seal | ⑯ Pinion rear bearing | ㉕ Pinion mate shaft |
| ⑧ Side bearing spacer | ⑰ Pinion height adjusting washer | ㉖ Side gear (L.H.) with viscous coupling |
| ⑨ Side bearing adjusting washer | ⑱ Hypoid gear set | |

FINAL DRIVE (Model R200V)

On-vehicle Service

FRONT OIL SEAL REPLACEMENT

1. Remove propeller shaft.
2. Loosen drive pinion nut with Tool.
Tool number: ST38060002



3. Remove companion flange.

4. Remove front oil seal.

5. Apply multi-purpose grease to sealing lips of oil seal. Press front oil seal into carrier.
6. Install companion flange and drive pinion nut.
7. Install propeller shaft.

SIDE OIL SEAL REPLACEMENT

1. Remove drive shafts.
Refer to RA section.
2. Remove oil seal.



FINAL DRIVE (Model R200V)

On-vehicle Service (Cont'd)

3. Apply multi-purpose grease to sealing lips of oil seal. Press-fit oil seal into carrier with Tool.

Tool number: KV38100200

4. Install drive shafts.




Removal

- Remove propeller shaft.
- Insert plug into rear oil seal after removing propeller shaft.**
- Remove drive shafts.
Refer to RA section.
 - Pull off final drive backward together with jack.

CAUTION:


- Be careful not to damage spline, sleeve yoke and front oil seal, when removing propeller shaft.
- After final drive is removed, support suspension member on a stand to prevent its insulators from being twisted or damaged.



Installation

- Installation is in the reverse order of removal.
- Fill final drive with recommended gear oil.

DISASSEMBLY (Model R200V)



Pre-inspection

Before disassembling final drive, perform the following inspection.

- Total preload
 - 1) Turn drive pinion in both directions several times to set bearing rollers.

- 2) Check total preload with Tool.

Tool number: ST3127S000

Total preload:

1.5 - 2.4 N·m


(16 - 25 kg-cm, 13.5 - 21.5 in-lb)



- Ring gear to drive pinion backlash
Check ring gear-to-drive pinion backlash with a dial indicator at several points.

Ring gear backlash:

0.13 - 0.18 mm (0.0039 - 0.0059 in)




Runout limit: 0.05 mm (0.0020 in)

- Ring gear runout
Check runout of ring gear with a dial indicator.

Runout limit:


0.05 mm (0.0020 in)

- Tooth contact
Check tooth contact. (Refer to Adjustment.)



Differential Carrier

1. Using two 45 mm (1.77 in) spacers, mount carrier on Tool.
Tool number: KV38100800




2. Paint or punch matchmarks on one side of the side bearing cap so it can be properly reinstalled.

Bearing caps are line-board during manufacture. Replace them in their proper positions.


DISASSEMBLY (Model R200V)

Differential Carrier (Cont'd)


3. Remove side bearing caps.





4. Lift differential case assembly out with Tool.
Tool number: HT72400000



Keep the side bearing outer races together with inner cone — do not mix them up.




5. Loosen drive pinion nut and extract companion flange with a puller.




DISASSEMBLY (Model R200V)


Differential Carrier (Cont'd)




6. Take out drive pinion (together with rear bearing inner race, bearing spacer and adjusting washer).
7. Remove front oil seal.
8. Remove front bearing inner race.
9. Remove side oil seals.



10. Remove pinion bearing outer races with a brass drift.



11. Remove pinion rear bearing inner race and drive pinion height adjusting washer with suitable tool.



Differential Case

1. Remove side bearing inner cones.
To prevent damage to bearing, engage puller jaws in groove.




Tool number:

- (A) ST33051001
- (B) ST33061000

DISASSEMBLY (Model R200V)


Differential Case (Cont'd)

Be careful not to confuse left- and right-hand parts.




2. Loosen ring gear bolts in a criss-cross fashion.
3. Tap ring gear off the differential case with a soft hammer.
Tap evenly all around to keep ring gear from binding.

4. Loosen screws on differential cases A and B.
5. Separate differential cases A and B.



Contact Surfaces

1. Clean the disassembled parts in suitable solvent and blow dry with compressed air.
2. If following surfaces are found to be burred or scratched, smooth with oil stone.
 - Differential case A
 - Differential case B
 - Side gear
 - Pinion mate gear
 - Pinion mate shaft
3. Check viscous coupling for oil leakage. If it is faulty, replace it with new one.



ADJUSTMENT (Model R200V)

Differential Case


THRUST WASHER SELECTION

Whenever side gears or pinion mate gears are replaced, select suitable thrust washers as follows:

1. Clean side gears and pinion mate gears using white gasoline.
2. Before assembling gears, apply hypoid gear oil to frictional surfaces.
3. Install the previously removed thrust washer on right side gear. On left side gear, install a suitable thrust washer. Temporarily tighten differential cases using two screws.
4. Position differential assembly so that right side gear is on the upper side. Place a 0.03 mm (0.0012 in) feeler gauge (for example) between right side gear and thrust washer.


Do not place feeler gauge at groove side of differential case.

5. Also place a 0.03 mm (0.0012 in) additional feeler gauge between right side gear and thrust washer so that it is positioned diagonal to (180° apart from) the feeler gauge described previously.
6. Rotate right side gear with a suitable tool attached to splines. If right side gear cannot be rotated, replace thrust washer used on left side gear with a thinner one.
7. Replace both 0.03 mm (0.0012 in) feeler gauges with 0.10 mm (0.0039 in) gauges. At this point, make sure right side gear does not rotate. If it does, replace thrust washer on left side gear with a thicker one so that right side gear does not rotate.
8. As explained in above example, select suitable thrust washers to ensure that:
 - a) Both side gears rotate. [0.03 mm (0.0012 in) feeler gauges are used in this case.]
 - b) Side gear is held stationary. [0.10 mm (0.0039 in) gauges are used in this case.]



ADJUSTMENT (Model R200V)


To avoid confusion while calculating bearing shims, it is absolutely necessary to stay with the metric system. If you measure anything in inches, **the results must be converted to the metric system.**



Drive Pinion Height


- First prepare Tools for pinion height adjustment.
 - Dummy Shaft (KV38103910)
 - Height Gauge (KV38100120)
 - Stopper (KV38100140)
 - Feeler Gauge
- To simplify the job, make a chart, like the one below, to organize your calculations.

LETTERS	HUNDREDTHS OF A MILLIMETER
H: Head number	
N: Measuring clearance	



- Write the following numbers down the chart.

H: Head number (stamped on head of drive pinion)



- Set Tool (Dummy shaft) as shown below and tighten drive pinion nut carefully to correct preload of 1.1 to 1.4 N·m (11 to 14 kg·cm, 9.5 to 12.2 in·lb).

Tool: Dummy shaft (KV38103910)

ADJUSTMENT (Model R200V)

Drive Pinion Height (Cont'd)

5. Attach Tool (Height gauge) to gear carrier, and measure the clearance between the height gauge and the dummy shaft face.
6. Substitute these values into the equation to calculate the thickness of the washer.

If value signifying H is not given, regard it as zero and calculate.

$$T \text{ (Thickness of washer)} = N - (H \times 0.01) + 3.08$$

Example:

$$\begin{aligned} N &= 0.24 \\ H &= 1 \end{aligned}$$

$$\begin{aligned} T &= N - (H \times 0.01) + 3.08 \\ &= 0.24 - (1 \times 0.01) + 3.08 \end{aligned}$$



(1)	H	1
		+ 1
(2)		+ 1
		x 0.01
		+ 0.01
(3)	N	0.24
		-
		(+ 0.01)
		0.23
(4)		0.23
		+ 3.08
		3.31
		∴ T = 3.31

7. Select the proper washer. (Refer to S.D.S.)

If you cannot find the desired thickness of washer, use washer with thickness closest to the calculated value.

Example:

$$\begin{aligned} \text{Calculated value ... } T &= 3.31 \text{ mm} \\ \text{Used washer ... } T &= 3.30 \text{ mm} \end{aligned}$$




ADJUSTMENT (Model R200V)


Side Bearing Preload

- To simplify the job, make a chart like the one below to organize your calculations.


LETTERS	HUNDREDTHS OF A MILLIMETER
A - Left housing	
B - Right housing	
C - Differential case	
D - Differential case	
E - Left side bearing	
F - Right side bearing	
G - Spacer measurement	
H - (+) or (-): ring gear	



- Write the following numbers down in the chart.
A & B: Figures marked on gear carrier



C & D: Figures marked on differential case





H: Figure marked on ring gear

ADJUSTMENT (Model R200V)

Side Bearing Preload (Cont'd)


G: This is the difference in thickness of side spacer against standard width [8.10 mm (0.3189 in)].
(G = Standard spacer – Measured spacer)



3. Measure how far under the standard thickness [21 mm (0.83 in)] the side bearings are.

It will require tools shown to the left.

- ① Weight Block (ST32501000)
- ② Master Gauge (KV38102000)
- ③ Base Plate
- ④ Dial Indicator



4. Place the outer race of the opposite side bearing to be measured on the base plate.


5. Place a weight block on that outer race, and a master gauge on that block.

Tool number:

- Ⓐ ST32501000
- Ⓑ KV38102000


6. Adjust dial indicator scale to zero.

7. Carefully slide master gauge block and weight block out from under dial indicator.



8. Lubricate side bearing and place the bearing outer race and inner cone to be measured on the opposite side outer race.

If the bearing assembly is placed on the base plate, the bearing width cannot be accurately determined due to its cage being in contact with the base plate.




9. Place weight block on side bearing.

10. Slide dial indicator on weight block.

ADJUSTMENT (Model R200V)

Side Bearing Preload (Cont'd)



11. Turn weight block a few times to ensure that bearing is properly seated.
12. Read dial indicator.
 - **Normal indication:**
0.10 - 0.30 mm (0.0039 - 0.0118 in)
 - **If the needle fluctuated erratically then bearing is either dirty or damaged and should be cleaned or replaced.**
13. Measure both bearings in the same way and write the left side bearing measurement next to "E" and the right side bearing measurement next to "F".
14. Substitute these values into the equation to calculate the thickness of the shim.

If values signifying A, B, C, D and H are not given, regard them as zero and calculate.

Left side

$$T_1 = (A - C + D + H) \times 0.01 + 1.97 + E + G$$

Right side

$$T_2 = (B - D - H) \times 0.01 + 2.07 + F$$

ADJUSTMENT (Model R200V)

Side Bearing Preload (Cont'd)

Example:

$$\begin{array}{ll} A = 4 & H = -2 \\ B = 3 & E = 0.18 \\ C = 5 & F = 0.15 \\ D = 6 & G = 0.08 \end{array}$$

Left side

$$\begin{aligned} T_1 &= (A - C + D + H) \times 0.01 + 1.97 + E + G \\ &= [4 - 5 + 6 + (-2)] \times 0.01 + 1.97 + 0.18 + 0.08 \end{aligned}$$

$$\begin{array}{rcl} (1) & A & \dots\dots\dots 4 \\ & - C & \dots\dots\dots -5 \end{array}$$

$$\hline \dots\dots\dots -1$$

$$+ D \dots\dots\dots +6$$

$$\hline 5$$

$$+ H \dots\dots\dots +(-2)$$

$$\hline 3$$

$$(2) \dots\dots\dots 3$$

$$\times 0.01$$

$$\hline 0.03$$

$$(3) \dots\dots\dots 0.03$$

$$+ 1.97$$

$$\hline 2.00$$

$$(4) \dots\dots\dots 2.00$$

$$+ E \dots\dots\dots +0.18$$

$$\hline 2.18$$

$$(5) \dots\dots\dots 2.18$$

$$+ G \dots\dots\dots +0.08$$

$$\hline 2.26$$

$$\therefore T_1 = 2.26 \text{ mm}$$

Right side

$$\begin{aligned} T_2 &= (B - D - H) \times 0.01 + 2.07 + F \\ &= [3 - 6 - (-2)] \times 0.01 + 2.07 + 0.15 \end{aligned}$$

$$(1) \quad B \dots\dots\dots 3$$

$$- D \dots\dots\dots -6$$

$$\hline -3$$

$$- H \dots\dots\dots -(-2)$$

$$\hline -1$$

$$(2) \dots\dots\dots -1$$

$$\times 0.01$$

$$\hline -0.01$$

$$(3) \dots\dots\dots -0.01$$

$$+ 2.07$$

$$\hline 2.06$$

$$(4) \dots\dots\dots 2.06$$

$$+ F \dots\dots\dots +0.15$$

$$\hline 2.21$$

$$\therefore T_2 = 2.21 \text{ mm}$$

15. Select the proper shims (Refer to S.D.S.).


If you cannot find the desired thickness of shims, use shims with the total thickness closest to the calculated value.

ADJUSTMENT (Model R200V)


Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear set which is not positioned properly in relation to one another may be noisy, or have short life or both. With the checking of gear tooth contact pattern, the most desirable contact for low noise level and long life can be assured.




1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.




3. Hold companion flange steady by hand and rotate the ring gear in both directions.

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.




SPD007

ASSEMBLY (Model R200V)



1. Place differential case on ring gear.
2. Apply locking sealant to ring gear bolts, and install them.
Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.




3. Press-fit side bearing inner cones on differential case with Tool.

Tool number:

(A) KV38100300

(B) ST33061000



4. Press-fit front and rear bearing outer races with Tools.


Tool number:

(A) ST30611000

(B) ST30613000

(C) ST30701000

5. Select pinion bearing adjusting washer and drive pinion bearing spacer, referring to ADJUSTMENT.




6. Install drive pinion height adjusting washer in drive pinion, and press-fit pinion rear bearing inner cone in it, using press and Tool.

Tool number: ST30901000


ASSEMBLY (Model R200V)



7. Place pinion front bearing inner cone in final drive housing.




8. Set drive pinion assembly with all parts, as shown in figure at left, in differential carrier.



9. Press drive pinion assembly into differential carrier, using a suitable tool.


Stop when drive pinion touches bearing.

Apply multi-purpose grease to pinion rear bearing inner race and pinion front bearing inner race.



10. Install front oil seal with Tool.

Tool number: KV38100500




11. Install companion flange, and tighten pinion nut to specified torque with Tool.

Ascertain that threaded portion of drive pinion and pinion nut are free from oil or grease.

Tool number: ST38060002

ASSEMBLY (Model R200V)




12. Turn drive pinion in both directions several times, and measure pinion bearing preload.

Pinion bearing preload:

1.1 - 1.7 N·m


(11 - 17 kg-cm, 9.5 - 14.7 in-lb)

When pinion bearing preload is outside the specifications, replace pinion bearing adjusting washer and spacer with a different thickness.




13. Select side bearing adjusting washers. Refer to ADJUSTMENT.

14. Install differential case assembly with side bearing outer races into gear carrier.




15. Insert left and right side bearing adjusting washers in place between side bearings and carrier.



16. Drive in side bearing spacer with Tool.


Tool number: KV38100600

- **Make sure that side bearing spacer is installed at correct side. See illustration.**



17. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.

ASSEMBLY (Model R200V)



18. Install side oil seal.

Tool number: KV38100200



19. Measure ring gear-to-drive pinion backlash with a dial indicator.


Ring gear backlash:

0.13 - 0.18 mm

(0.0050 - 0.0071 in)

- If backlash is too small, decrease thickness of left shim and increase thickness of right shim by the same amount. If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.



20. Check total preload with Tool.

When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.

Total preload:


1.5 - 2.4 N·m

(16 - 25 kg-cm, 13.5 - 21.5 in-lb)

- If preload is too great, remove the same amount of shim to each side.
- If preload is too small, add the same amount of shim to each side.

Never add or remove a different number of shims for each side as it will change ring gear backlash.

21. Recheck ring gear backlash because increase or decrease in thickness of shims will cause change of ring gear-to-pinion backlash.



22. Check runout of ring gear with a dial indicator.

Runout limit: 0.05 mm (0.0020 in)


- If backlash varies excessively in different places, foreign matter may be caught between the ring gear and the differential case.
- If the backlash varies greatly when the ring gear runout is within a specified range, replace the hypoid gear set or differential case.

23. Check tooth contact.

Refer to ADJUSTMENT.

24. Install rear cover and gasket.

FINAL DRIVE (Model H190A)




SPD562A

- ① Companion flange
- ② Front oil seal
- ③ Pinion front bearing
- ④ Gear carrier
- ⑤ Gasket
- ⑥ Collapsible spacer
- ⑦ Drive pinion washer
- ⑧ Pinion rear bearing

- ⑨ Drive pinion height adjusting washer
- ⑩ Hypoid gear set
- ⑪ Side bearing adjusting shim
- ⑫ Side bearing
- ⑬ Side bearing cap
- ⑭ Lock strap

- ⑮ Differential case
- ⑯ Side gear thrust washer
- ⑰ Side gear
- ⑱ Lock pin
- ⑲ Pinion mate gear
- ⑳ Pinion mate thrust washer
- ㉑ Pinion mate shaft

DISASSEMBLY (Model H190A)



Pre-inspection

Before disassembling final drive, perform the following inspection.

- Total preload
 - 1) Turn drive pinion in both directions several revolutions to seat bearing rollers correctly.
 - 2) Check total preload with Tool.

Tool number: ST3127S000

Total preload:



1.4 - 2.4 N·m

(15 - 25 kg-cm, 13 - 21.5 in-lb)

- Ring gear to drive pinion backlash
Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:


0.13 - 0.18 mm (0.0051 - 0.0071 in)



- Ring gear runout
Check runout of ring gear with a dial indicator.

Runout limit:


0.08 mm (0.0031 in)



- Tooth contact
Check tooth contact, referring to Adjustment.
- Side gear to pinion mate gear backlash
Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:

0 - 0.20 mm (0 - 0.0079 in)



Differential Carrier

1. Mount differential carrier on Tools.

Tool number:

(A) ST0501S000



(B) ST06310000

DISASSEMBLY (Model H190A)


Differential Carrier (Cont'd)

2. Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.

Bearing caps are line-bored during manufacture and should be put back in their original places.




3. Remove side bearing caps.




4. Remove differential case assembly with a pry bar.

Be careful to keep the side bearing outer races together with their respective inner cones – do not mix them up.



5. Remove drive pinion nut with Tool.


Tool number: ST38060002



DISASSEMBLY (Model H190A)


Differential Carrier (Cont'd)

6. Remove companion flange with puller.




7. Remove drive pinion with soft hammer.

8. Remove oil seal.




9. Remove pinion bearing outer races with a brass drift.



10. Pull out rear bearing inner cone with a press and Tool.

Be carefull not to damage cage of bearing.

Tool number: SWT30031000



DISASSEMBLY (Model H190A)

Differential Case



1. Remove side bearing inner cones.

To prevent damage to bearing, engage puller jaws in groove.


Tool number:

(A) ST33051001

(B) ST33061000




Be careful not to confuse left and right hand parts.



2. Spread out lock straps and loosen ring gear bolts in a criss-cross fashion.

3. Tap ring gear off differential case with a soft hammer.

Tap evenly all around to prevent ring gear from binding.




4. Drive out pinion mate shaft lock pin, with Tool from ring gear side.

Lock pin is caulked at pin hole mouth on differential case.


Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping.
If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).



Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, and thrust washers.




Bearing

1. Thoroughly clean bearing.
2. Check bearings for wear, scratches, pitting or flaking.
Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



LIMITED SLIP DIFFERENTIAL (For H190A)



CAUTION:

Do not run engine when one wheel (rear) is off the ground.

Preparation for Disassembly

CHECKING DIFFERENTIAL TORQUE

Measure differential torque with Tool.


If it is not within the specifications, inspect components of limited slip differential.

Differential torque:


147 - 196 N·m
 (15 - 20 kg-m, 108 - 145 ft-lb)

Tool number:

- (A) KV38105210
- (B) KV38105220




LIMITED SLIP DIFFERENTIAL (For H190A)



Disassembly

1. Remove side bearing inner cone with Tool.
 2. Remove ring gear by spreading out lock straps.
 3. Loosen ring gear bolts in a criss-cross fashion.
 4. Tap ring gear off gear case with a soft hammer.
- Tap evenly all around to prevent ring gear from binding.**




5. Remove differential case by spreading out lock straps.
6. Remove couple bolts on differential cases A and B with a press.

Tool number: ST33081000

7. Separate differential case A and B.
Draw out component parts (discs and plates, etc.).

Put marks on gears and pressure rings so that they can be reinstalled in their original positions from which they were removed.



Inspection

CONTACT SURFACES

1. Clean the disassembled parts in suitable solvent and blow dry with compressed air.
2. If following surfaces are found with burrs or scratches, smooth with oil stone.
 - ① Differential case A
 - ② Differential case B
 - ③ Side gear
 - ④ Pinion mate gear
 - ⑤ Pinion mate shaft
 - ⑥ Thrust block
 - ⑦ Friction plate guide

DISC AND PLATE

1. Clean the discs and plates in suitable solvent and blow dry with compressed air.
2. Inspect discs and plates for wear, nicks and burrs.

LIMITED SLIP DIFFERENTIAL (For H190A)

Inspection (Cont'd)

3. To test if friction disc or plate is not distorted, place it on a surface plate and rotate it by hand with indicating finger of dial gauge resting against disc or plate surface.

Allowable warpage:

0.05 - 0.20 mm (0.0020 - 0.0079 in)


If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.

4. Measure frictional surfaces and projected portions of friction disc, friction plate, spring plate, and determine each part's differences to see if the specified wear limit has been exceeded.



If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:


0.1 mm (0.004 in) or less



SPD279



SPD403



SPD761

Adjustment

FRICITION DISC AND FRICTION PLATE END PLAY

End play of friction disc and friction plate can be calculated by using following equation and should be adjusted within following range.

Adjustment can be made by selecting friction disc having two different thicknesses.

End play E:


0.05 - 0.20 mm (0.0020 - 0.0079 in)

$$E = A - (B + C)$$

- A: Length of differential case contact surface to differential case inner bottom.
B: Total thickness of friction discs, friction plates, spring disc and spring plate in differential case on one side.
C: Length of differential case contact surface to back side of side gear.

LIMITED SLIP DIFFERENTIAL (For H190A)


Adjustment (Cont'd)



1. Measure values of "A".

Standard length A:

45.55 - 45.60 mm (1.7933 - 1.7953 in)




2. Measure thickness of each disc and plate.

Total thickness "B":

10.38 - 10.62 mm (0.4087 - 0.4181 in)

No. of discs and plates (One side)

Model	H190A
Friction disc	2
Friction plate	2
Spring disc	1
Spring plate	1




3. Measure values of "C".

(1) Attach a dial indicator to the base plate.

(2) Place differential case B on the base plate, and install a master gauge on case B.

Then adjust the dial indicator scale to zero with its tip on the master gauge.



(3) Install pinion mate gears, side gears and pinion mate shaft in differential case B.

(4) Set dial indicator's tip on the side gear, and read the indication.

Example:

$$\begin{aligned}
 E &= A - D \\
 &= A - (B + C) \\
 &= 0.05 \text{ to } 0.2 \text{ mm}
 \end{aligned}$$

$$A = 45.58 \text{ mm}$$

$$B = 10.4 \text{ mm}$$

$$C = 34.93 \text{ mm}$$

$$D = B + C$$

$$B \dots 10.4$$

$$+ C \dots 34.93$$

$$\hline 45.33$$

$$E = A - D$$

$$A \dots 45.58$$

$$- D \dots 45.33$$

$$\hline 0.25$$

From the above equation, end play of 0.25 mm exceeds the specified range of 0.05 to 0.2 mm.

Select suitable discs and plates to adjust correctly.

LIMITED SLIP DIFFERENTIAL (For H190A)

Assembly

Prior to assembling discs and plates, properly lubricate them by dipping them in limited slip differential oil.

1. Alternately position specified number of friction plates and friction discs on rear of side gear.

Always position a friction plate first on rear of side gear.

2. Install spring disc.

Align the twelve angular holes in spring disc with the hexagonal area of the side gear.






3. Install spring plate.

4. Install friction plate guides.

Correctly align the raised portions of friction plates, and apply grease to inner surfaces of friction plate guides to prevent them from falling.


5. Install differential case B over side gear, discs, plates and friction plate guide assembly.

- Install differential case B while supporting friction plate guides with your middle finger inserted through oil hole in differential case.
- Be careful not to detach spring disc from the hexagonal part of the side gear.




LIMITED SLIP DIFFERENTIAL (For H190A)


Assembly (Cont'd)



6. Install pinion mate gears and pinion shaft to differential case B.




7. Install thrust block.



8. Install side gear to pinion mate gears.

9. Install each disc and plate.

Use same procedures as outlined in steps 1. through 4. above.



10. Install differential case A.

Position differential cases A and B by correctly aligning marks stamped on cases.



11. Tighten differential case bolts.

12. Place ring gear on differential case and install new lock straps and bolts.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.


Then bend up lock straps to lock the bolts in place.

13. Install side bearing inner cone.

14. Check differential torque.

ADJUSTMENT (Model H190A)

To avoid confusion while calculating bearing shims, it is absolutely necessary to stay with the metric system. If you measure anything in inches, **the results MUST be converted to the metric system.**




Drive Pinion Height

1. First prepare Tools for pinion height adjustment.


- ① Height Gauge (ST31941000)
- ② Dummy Shaft (ST31942000)
- ③ Collar (ST31970000)
- ④ Feeler Gauge

2. To simplify the job, make a chart, like the one below, to organize your calculations.

LETTERS	HUNDREDTHS OF A MILLIMETER
H: Head number	
D': Figure marked on dummy shaft	
S: Figure marked on height gauge	
N: Measuring clearance	



3. Write the following numbers down in the chart.
H: Head number





- D': Figure marked on dummy shaft


ADJUSTMENT (Model H190A)

Drive Pinion Height (Cont'd)

S: Figure marked on height gauge



4. Place pinion rear bearing inner cone and Tools on gear carrier.



5. Attach Tool (Height gauge) to gear carrier, and measure the clearance between the height gauge tip and the dummy shaft face.

ADJUSTMENT (Model H190A)

Drive Pinion Height (Cont'd)

6. Substitute these values into the equation to calculate the thickness of the washer.

If values signifying H, D' and S are not given, regard them as zero and calculate.

T (Thickness of washer) = $N - [(H - D' - S) \times 0.01] + 2.18$
Example:

$$N = 0.46$$

$$H = -4$$

$$D' = -3$$

$$S = 0$$

$$T = N - [(H - D' - S) \times 0.01] + 2.18$$

$$= 0.46 - [((-4) - (-3) - 0) \times 0.01] + 2.18$$

(1)	H	(- 4)
	- D'	- (- 3)
		- 1
	- S	- 0
		- 1
(2)		- 1
		x 0.01
		- 0.01
(3)	N	0.46
		- (- 0.01)
		0.47
(4)		0.47
		+ 2.18
		2.65
		$\therefore T = 2.65$

7. Select the proper washer (Refer to S.D.S.).

If you cannot find the desired thickness of washer, use washer with thickness closest to the calculated value.

Example:

Calculated value ... $T = 2.65$ mm


Used washer ... $T = 2.64$ mm

ADJUSTMENT (Model H190A)


Side Bearing Preload

- To simplify the job, make a chart like the one below to organize your calculations.


LETTERS	HUNDREDTHS OF A MILLIMETER
A - Left housing	
B - Right housing	
C - Differential case	
D - Differential case	
E - Left side bearing	
F - Right side bearing	
H - (+) or (-): ring gear	



- Write the following numbers down in the chart.
A & B: Figures marked on gear carrier




C & D: Figures marked on differential case



H: Figures marked on ring gear


ADJUSTMENT (Model H190A)

Side Bearing Preload (Cont'd)




3. Measure how far under the standard thickness [20 mm (0.79 in)] the side bearings are. It will require tools shown in the illustration at left.

- ① Weight Block (ST32501000)
- ② Master Gauge (KV38101900)
- ③ Base Plate
- ④ Dial Indicator




- 4. Place the outer race of the opposite side bearing to be measured.
- 5. Place a weight block on that outer race, and a master gauge on that block.
- 6. Adjust dial indicator scale to zero.
- 7. Carefully slide master gauge and weight block out from under dial indicator.




8. Lubricate side bearing and place the bearing outer race and inner race to be measured on the opposite side outer race.

If the bearing assembly is placed on the base plate, the bearing width cannot be accurately determined due to its cage being in contact with the base plate.



- 9. Place weight block on side bearing.
- 10. Slide dial indicator on weight block.



- 11. Turn weight block a few times to ensure that bearing is properly seated.
- 12. Read dial indicator.
 - **Normal indication:**
0.10 - 0.30 mm (0.0039 - 0.0118 in)
 - If the needle fluctuates erratically then bearing is either dirty or defective and should be cleaned or replaced.

ADJUSTMENT (Model H190A)

Side Bearing Preload (Cont'd)

13. Measure both bearings in the same way and write the left side bearing measurement next to "E" and the right side bearing measurement next to "F".
14. Substitute these values into the equation to calculate the thickness of the shim.

If values signifying A, B, C, D and H' are not given, regard them as zero and calculate.

Ring gear with "+":

Left side:

$$T_1 = (A - C + D - H') \times 0.01 + 0.175 + E$$

Right side:

$$T_2 = (B - D + H') \times 0.01 + 0.15 + F$$

Ring gear with "-":

Left side:

$$T_1 = (A - C + D + H') \times 0.01 + 0.175 + E$$

Right side:

$$T_2 = (B - D - H') \times 0.01 + 0.150 + F$$

Example:

A = 1	H = -2
B = 2	E = 0.11
C = 2	F = 0.18
D = 3	

Left side

$$T_1 = (A - C + D + H') \times 0.01 + 0.175 + E$$

$$= [1 - 2 + 3 + (-2)] \times 0.01 + 0.175 + 0.11$$

Right side

$$T_2 = (B - D - H') \times 0.01 + 0.15 + F$$

$$= [2 - 3 - (-2)] \times 0.01 + 0.15 + 0.18$$

(1)	A	1							
	- C	-2							
		-1							
	+ D	+3							
		2							
	- H'	+(-2)							
		0							
(2)		0							
		x 0.01							
		0.00							
(3)		0.00							
		+0.175							
		0.175							
(4)		0.175							
	+ E	+0.11							
		0.285							

$$\therefore T_1 = 0.285 \text{ mm}$$

(1)	B	2							
	- D	-3							
		-1							
	+ H'	-(-2)							
		+1							
		+1							
		x 0.01							
		+0.01							
(3)		+0.01							
		+0.15							
		0.16							
(4)		0.16							
	+ F	+0.18							
		0.34							

$$\therefore T_2 = 0.34 \text{ mm}$$

15. Select the proper shims (Refer to S.D.S.).

If you cannot find the desired thickness of shims, use shims with the total thickness closest to the calculated value.


ADJUSTMENT (Model H190A)

Tooth Contact


Checking of gear tooth contact pattern is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear set which are not positioned properly in relation to one another may be noisy, or have short life or both. With the checking of gear tooth contact pattern, the most desirable contact for low noise level and long life can be assured.


1. Thoroughly clean ring gear and drive pinion teeth.
2. Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.



3. Hold companion flange steady by hand and rotate the ring gear in both directions.



Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.



When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.

SPD007

ADJUSTMENT (Model H190A)

Side Bearing Preload (Cont'd)

13. Measure both bearings in the same way and write the left side bearing measurement next to "E" and the right side bearing measurement next to "F".
14. Substitute these values into the equation to calculate the thickness of the shim.

If values signifying A, B, C, D and H' are not given, regard them as zero and calculate.

Ring gear with "+":

Left side:

$$T_1 = (A - C + D - H') \times 0.01 + 0.175 + E$$

Right side:

$$T_2 = (B - D + H') \times 0.01 + 0.15 + F$$

Ring gear with "-":

Left side:

$$T_1 = (A - C + D + H') \times 0.01 + 0.175 + E$$

Right side:

$$T_2 = (B - D - H') \times 0.01 + 0.150 + F$$

Example:

$$\begin{array}{ll} A = 1 & H = -2 \\ B = 2 & E = 0.11 \\ C = 2 & F = 0.18 \\ D = 3 & \end{array}$$

Left side

$$\begin{aligned} T_1 &= (A - C + D + H') \times 0.01 + 0.175 + E \\ &= [1 - 2 + 3 + (-2)] \times 0.01 + 0.175 + 0.11 \end{aligned}$$

(1)	A	1							
	- C	-2							
		-1							
	+ D	+3							
		2							
	- H'	+(-2)							
		0							
(2)		0							
		x 0.01							
		0.00							
(3)		0.00							
		+0.175							
		0.175							
(4)		0.175							
	+ E	+0.11							
		0.285							

$$\therefore T_1 = 0.285 \text{ mm}$$

Right side

$$\begin{aligned} T_2 &= (B - D - H') \times 0.01 + 0.15 + F \\ &= [2 - 3 - (-2)] \times 0.01 + 0.15 + 0.18 \end{aligned}$$

(1)	B	2							
	- D	-3							
		-1							
	+ H'	-(-2)							
		+1							
		+1							
		x 0.01							
		+0.01							
(3)		+0.01							
		+0.15							
		0.16							
(4)		0.16							
	+ F	+0.18							
		0.34							

$$\therefore T_2 = 0.34 \text{ mm}$$


15. Select the proper shims (Refer to S.D.S.).

If you cannot find the desired thickness of shims, use shims with the total thickness closest to the calculated value.

ASSEMBLY (Model H190A)

Differential Case


1. Install side gears, pinion mate gears and thrust washers into differential case.




2. Fit pinion mate shaft to differential case so that it meets lock pin holes.
3. Adjust backlash between side gear and pinion mate gear by selecting side gear thrust washer (Refer to S.D.S.).

**Backlash between side gear and pinion mate gear
(Clearance between side gear thrust washer and differential case)**

0 - 0.20 mm (0 - 0.0079 in)



4. Install pinion mate shaft lock pin with a punch.
Make sure lock pin is flush with case.




5. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




6. Apply locking agent [Locktite (stud lock) or equivalent] to contacting surfaces of ring gear and differential case, then place differential case on ring gear.

ASSEMBLY (Model H190A)

Differential Case (Cont'd)



7. Apply a small amount of locking agent (described on previous page) to ring gear bolts.
8. Install new lock straps and ring gear bolts.
 - Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.
 - Then bend up lock straps to lock the bolts in place.




9. Select side bearing adjusting shims. Refer to Adjustment.
10. Install the shims behind each bearing and press on side bearing inner cones with Tool.

Tool number:

- (A) ST33230000
- (B) ST33061000


Differential Carrier



1. Press fit front and rear bearing outer races with Tools.

Tool number:

- (A) ST30611000
- (B) ST30621000
- (C) ST30613000



2. Select pinion height adjusting washer, referring to Adjustment.
3. Install pinion height adjusting washer in drive pinion, and press fit rear bearing inner cone in it with press and Tool.


Tool number: ST30901000

ASSEMBLY (Model H190A)

Differential Carrier (Cont'd)



4. Place pinion front bearing inner cone in gear carrier.




5. Apply multi-purpose grease to cavity at sealing lips of oil seal.

Install front oil seal.


Tool number:

A ST30720000


B KV38102510



6. Install drive pinion washer, collapsible spacer and drive pinion in gear carrier.



7. Install companion flange and hold it firmly.
Insert pinion into companion flange by tapping its head with a soft hammer.



8. Temporarily tighten pinion nut until there is no axial play.
The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number: ST38060002

ASSEMBLY (Model H190A)

Differential Carrier (Cont'd)

9. Tighten pinion nut by degrees to the specified preload while checking the preload with Tools.

When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.

Pinion bearing preload:

1.2 - 1.7 N·m (13 - 18 kg-cm, 11.15 - 15.3 in-lb)

Tool number: ST3127S000

CAUTION:

The preload is achieved by using the permanent set of collapsible spacer. So here, if an overpreload results from excessive turning of the pinion nut, the spacer should be replaced by new one.

10. Install differential case assembly with side bearing outer races into gear carrier.

11. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.

12. Measure ring gear-to-drive pinion backlash with a dial indicator.

Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)

- If backlash is too small, decrease thickness of left shim and increase thickness of right shim by the same amount.
- If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.






13. Check total preload with Tool.

When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number: ST3127S000


Total preload:

1.4 - 2.4 N·m (15 - 25 kg-cm, 13 - 21.5 in-lb)



ASSEMBLY (Model H190A)


Differential Carrier (Cont'd)



- If preload is too great, remove the same amount of shims from each side.
- If preload is too small, add the same amount of shims to each side.

Never add or remove a different number of shims for each side as it will change gear-to-drive pinion backlash.

14. Recheck ring gear-to-drive pinion backlash because an increase or decrease in thickness of shims will cause change of ring gear-to-drive pinion backlash.



15. Check runout of ring gear with a dial indicator.

Runout limit: 0.08 mm (0.0031 in)

- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
- If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.

16. Check tooth contact.
Refer to Adjustment.

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Propeller Shaft

GENERAL SPECIFICATIONS

Unit: mm (in)

Propeller shaft model	2S63A
Number of joints	2
Coupling method with transmission	Sleeve type
Type of journal bearings	Shell type (Non-disassembly type)
Shaft length (Spider to spider)	
SR20DE, LD20-II	545 (22.63)
GA16DE	575 (22.63)
Shaft outer diameter	75.0 (2.953)

SPECIFICATIONS AND ADJUSTMENT

Unit: mm (in)

Propeller shaft runout limit	0.6 (0.024)
Journal axial play	0 (0)

Final Drive

GENERAL SPECIFICATIONS

Engine	GA16DE	LD20-II	SR20DE
Final drive model	H190A/H190A (LSD)*		R200V
Ring gear pitch diameter mm (in)	193 (7.59)		205 (8.07)
Gear ratio	4.636	4.363	
Number of teeth (Ring gear/Drive pinion)	51/11	48/11	
Oil capacity (approx.) ℓ (Imp pt)	1.5 (2-5/8)		1.3 (2-1/4)
Number of pinion gears	4		4
Side bearing spacer location	Left		

* Option

INSPECTION AND ADJUSTMENT (R200V)

Ring gear runout

Ring gear runout limit mm (in)	0.05 (0.0020)
-----------------------------------	---------------

Side gear adjustment

Clearance between side gear and differential case mm (in)	0.03 - 0.09 (0.0012 - 0.0035)
---	----------------------------------

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Final Drive (Cont'd)

Available side gear thrust washers

Thickness	mm (in)	Part number
0.80 (0.0315)		38424-40F60
0.83 (0.0327)		38424-40F61
0.86 (0.0339)		38424-40F62
0.89 (0.0350)		38424-40F63
0.92 (0.0362)		38424-40F64
0.95 (0.0374)		38424-40F65
0.98 (0.0386)		38424-40F66
1.01 (0.0398)		38424-40F67
1.04 (0.0409)		38424-40F68
1.07 (0.0421)		38424-40F69
1.10 (0.0433)		38424-40F70
1.13 (0.0445)		38424-40F71
1.16 (0.0457)		38424-40F72
1.19 (0.0469)		38424-40F73
1.22 (0.0480)		38424-40F74
1.25 (0.0492)		38424-40F75
1.28 (0.0504)		38424-40F76
1.31 (0.0516)		38424-40F77
1.34 (0.0528)		38424-40F78
1.37 (0.0539)		38424-40F79
1.40 (0.0551)		38424-40F80
1.43 (0.0563)		38424-40F81
1.46 (0.0575)		38424-40F82
1.49 (0.0587)		38424-40F83

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness	mm (in)	Part number
3.09 (0.1217)		38154-P6017
3.12 (0.1228)		38154-P6018
3.15 (0.1240)		38154-P6019
3.18 (0.1252)		38154-P6020
3.21 (0.1264)		38154-P6021
3.24 (0.1276)		38154-P6022
3.27 (0.1287)		38154-P6023
3.30 (0.1299)		38154-P6024
3.33 (0.1311)		38154-P6025
3.36 (0.1323)		38154-P6026
3.39 (0.1335)		38154-P6027
3.42 (0.1346)		38154-P6028
3.45 (0.1358)		38154-P6029
3.48 (0.1370)		38154-P6030
3.51 (0.1382)		38154-P6031
3.54 (0.1394)		38154-P6032
3.57 (0.1406)		38154-P6033
3.60 (0.1417)		38154-P6034
3.63 (0.1429)		38154-P6035
3.66 (0.1441)		38154-P6036

Drive pinion preload adjustment

Drive pinion bearing adjusting method	Pinion bearing adjusting washer and spacer
Drive pinion preload with front oil seal	1.1 - 1.7 (11 - 17, 9.5 - 14.7) N·m (kg-cm, in-lb)

Available drive pinion bearing preload adjusting washers

Thickness	mm (in)	Part number
3.80 - 3.82 (0.1496 - 0.1504)		38125-61001
3.82 - 3.84 (0.1504 - 0.1512)		38126-61001
3.84 - 3.86 (0.1512 - 0.1520)		38127-61001
3.86 - 3.88 (0.1520 - 0.1528)		38128-61001
3.88 - 3.90 (0.1528 - 0.1535)		38129-61001
3.90 - 3.92 (0.1535 - 0.1543)		38130-61001
3.92 - 3.94 (0.1543 - 0.1551)		38131-61001
3.94 - 3.96 (0.1551 - 0.1559)		38132-61001
3.96 - 3.98 (0.1559 - 0.1567)		38133-61001
3.98 - 4.00 (0.1567 - 0.1575)		38134-61001
4.00 - 4.02 (0.1575 - 0.1583)		38135-61001
4.02 - 4.04 (0.1583 - 0.1591)		38136-61001
4.04 - 4.06 (0.1591 - 0.1598)		38137-61001
4.06 - 4.08 (0.1598 - 0.1606)		38138-61001
4.08 - 4.10 (0.1606 - 0.1614)		38139-61001

Available drive pinion bearing preload adjusting spacers

Length	mm (in)	Part number
54.50 (2.1457)		38165-B4000
54.80 (2.1575)		38165-B4001
55.10 (2.1693)		38165-B4002
55.40 (2.1811)		38165-B4003
55.70 (2.1929)		38165-B4004
56.00 (2.2047)		38165-61001

Total preload adjustment

Drive pinion to ring gear backlash	mm (in)	0.13 - 0.18 (0.0039 - 0.0059)
Total preload	N·m (kg-cm, in-lb)	1.5 - 2.4 (16 - 25, 13 - 21.5)

Available side bearing adjusting washers

Thickness	mm (in)	Part number
2.00 (0.0787)		38453-G9500
2.05 (0.0807)		38453-G9501
2.10 (0.0827)		38453-G9502
2.15 (0.0846)		38453-G9503
2.20 (0.0866)		38453-G9504
2.25 (0.0886)		38453-G9505
2.30 (0.0906)		38453-G9506
2.35 (0.0925)		38453-G9507
2.40 (0.0945)		38453-G9508
2.45 (0.0965)		38453-G9509
2.50 (0.0984)		38453-G9510
2.55 (0.1004)		38453-G9511
2.60 (0.1024)		38453-G9512
2.65 (0.1043)		38453-G9513

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (H190A)

Ring gear runout

Ring gear runout limit mm (in)	0.08 (0.0031)
--------------------------------	---------------

Side gear adjustment

Side gear backlash (Clearance between side gear and differential case) mm (in)	0 - 0.20 (0 - 0.0079)
--	--------------------------

Available side gear thrust washers

Conventional models

Thickness mm (in)	Part number
0.775 (0.0305)	38424-E3000
0.825 (0.0325)	38424-E3001
0.875 (0.0344)	38424-E3002
0.925 (0.0364)	38424-E3003

L.S.D. models

Thickness mm (in)	ID color	Part number
1.50 (0.0591)	None	38424-41W00
1.60 (0.0630)	White	38424-41W01
1.70 (0.0669)	Yellow	38424-41W02

- Additional service for limited slip differential model - Differential torque adjustment

Differential torque N·m (kg-m, ft-lb)	147 - 196 (15 - 20, 108 - 145)
--	-----------------------------------

Number of discs and plates (One side)	
Friction disc	2
Friction plate	2
Spring disc	1
Spring plate	1

Wear limit of plate and disc mm (in)	0.1 (0.004) or less
---	---------------------

Allowable warpage Friction disc and plate mm (in)	0.05 - 0.20 (0.0020 - 0.0079)
---	----------------------------------

Available discs and plates

Part name	Thickness mm (in)	Part number
Friction disc	1.73 - 1.77 (0.0681 - 0.0697)	38433-N9000
	1.83 - 1.87 (0.0720 - 0.0736)	38433-N9001
Friction plate	1.73 - 1.77 (0.0681 - 0.0697)	38432-N9000
Spring disc	1.74 - 1.76 (0.0685 - 0.0693)	38436-N3210
Spring plate	1.74 - 1.76 (0.0685 - 0.0693)	38435-N3210

Drive pinion height adjustment

Available drive pinion preload adjusting washers

Thickness mm (in)	Part number
2.58 (0.1016)	38154-P6000
2.61 (0.1028)	38154-P6001
2.64 (0.1039)	38154-P6002
2.67 (0.1051)	38154-P6003
2.70 (0.1063)	38154-P6004
2.73 (0.1075)	38154-P6005
2.76 (0.1087)	38154-P6006
2.79 (0.1098)	38154-P6007
2.82 (0.1110)	38154-P6008
2.85 (0.1122)	38154-P6009
2.88 (0.1134)	38154-P6010
2.91 (0.1146)	38154-P6011
2.94 (0.1157)	38154-P6012
2.97 (0.1169)	38154-P6013
3.00 (0.1181)	38154-P6014
3.03 (0.1193)	38154-P6015
3.06 (0.1205)	38154-P6016
3.09 (0.1217)	38154-P6017
3.12 (0.1228)	38154-P6018
3.15 (0.1240)	38154-P6019
3.18 (0.1252)	38154-P6020

Drive pinion preload adjustment

Drive pinion preload N·m (kg-cm, in-lb)	1.2 - 1.7 (13 - 18, 11 - 15.3)
With front oil seal	

Side bearing adjustment

Available side bearing adjusting shims

Thickness mm (in)	Part number
0.10 (0.0039)	38455-61200
0.12 (0.0047)	38453-61201
0.15 (0.0059)	38453-61202
0.17 (0.0066)	38453-61203
0.20 (0.0078)	38453-61200
0.25 (0.0098)	38453-61204
0.30 (0.0118)	38453-61205
0.40 (0.0157)	38453-61206
0.50 (0.0196)	38453-61200

Total preload adjustment

Total preload N·m (kg-cm, in-lb)	1.4 - 2.4 (15 - 25, 13 - 21.5)
Ring gear backlash mm (in)	0.13 - 0.18 (0.0051 - 0.0071)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Tightening Torque

Model R200V

Unit	N·m	kg-m	ft-lb
Final drive installation			
Companion flange to propeller shaft	39 - 44	4.0 - 4.5	29 - 33
Final drive assembly			
Drive pinion nut	186 - 294	19 - 30	137 - 217
Rear cover nuts	39 - 49	4.0 - 5.0	29 - 36
Ring gear bolts	132 - 152	13.5 - 15.5	97.5 - 112
Side bearing cap bolts	88 - 98	9.0 - 10	65 - 72
Drain and filler plugs	39 - 59	4.0 - 6.0	29 - 43

Model H190A

Unit	N·m	kg-m	ft-lb
Final drive installation			
Differential carrier to rear axle case fixing bolt	16 - 24	1.6 - 2.4	12 - 17
Companion flange to propeller shaft	39 - 44	4.0 - 4.5	29 - 33
Final drive assembly			
Drive pinion nut	127 - 294	13 - 30	94 - 217
Ring gear bolt	132 - 152	13.5 - 15.5	98 - 112
Side bearing cap bolt	49 - 59	5 - 6	36 - 43
Drain and filler plugs	59 - 98	6 - 10	43 - 72