



SEF135K

Check idle speed.

☒ Read idle speed in "DATA MONITOR" mode with CONSULT.
OR
☒ Check idle speed.

750 ± 50 rpm

O.K.

N.G.

Check A.A.C. valve and replace if necessary.


Check A.A.C. valve harness and repair if necessary.

Check E.C.U. function* by substituting another known good E.C.U.


* E.C.U. may be the cause of a problem, but this is rarely the case.



SEF320K



EEF007



SEF621K



1. See "M/R F/C MNT" in "Data monitor" mode.
2. Run engine at about 2,000 rpm for about 2 minutes under no-load.
3. Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH → LEAN → RICH →

1 time

2 times

LEAN → RICH.....

OR




1. Set "Exhaust gas sensor monitor" in the self-diagnostic mode II. (See page EF & EC-222).
2. Run engine at about 2,000 rpm for about 2 minutes under no-load.
3. Maintaining engine at 2,000 rpm under no-load, check to make sure that the RED L.E.D. on the E.C.U. or the check engine light on the instrument panel goes ON and OFF more than 5 times during 10 seconds.

O.K.

N.G.


C

END



As for the location of exhaust gas sensor harness connector, refer to page EF&EC-294

SEC240B



SEC241B

Check exhaust gas sensor harness:

- 1) Turn off engine and disconnect battery ground cable.
- 2) Disconnect E.C.U. S.M.J. harness connector from E.C.U.
- 3) Disconnect exhaust gas sensor harness connector and connect main harness side terminal for exhaust gas sensor to ground with a jumper wire.
- 4) Check for continuity between terminal No. (19) of E.C.U. S.M.J. harness connector and body ground.

Continuity exists O.K.
Continuity does not exist N.G.

O.K.

N.G.

Repair or replace harness.

Connect E.C.U. S.M.J. harness connector to control unit.

Connect battery ground cable.



SEF321K




- 1) Select "ENG TEMPERATURE" in "ACTIVE TEST" mode.
- 2) Set "ENGINE TEMP" to 20°C (68°F) by touching "Qu" and "Qd" and "UP", "DOWN".

OR




- 1) Disconnect engine temperature sensor harness connector.
- 2) Connect a resistor (2.5 kΩ) between terminals of engine temperature sensor harness connector.

Start engine and warm it up until water temperature indicator points to middle of gauge.




SEC242B



EEF008

D



EEF045

Race engine two or three times under no-load, then run engine at idle speed.

Check "CO"%.
Remove test-take off plug and insert "CO" meter probe into test-take off tube sealing with a suitable cap.

Idle CO: Less than 1.0%

After checking CO%,

1) Touch "BACK".

- 1) Disconnect the resistor from terminals of engine temperature sensor harness connector.
- 2) Connect engine temperature sensor harness connector to engine temperature sensor.

N.G.

Replace exhaust gas sensor.


- 1) See "M/R F/C MNT" in "Data monitor" mode
- 2) Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently.), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
RICH → LEAN → RICH →
1 time 2 times →

LEAN → RICH
OR

- 1) Set "Exhaust gas sensor monitor" in the self-diagnostic mode II. (See page EF & EC-222.)
- 2) Maintaining engine at 2,000 rpm under no-load, check to make sure that the RED L.E.D. on the E.C.U. or the check engine light on the instrument panel goes ON and OFF more than 5 times during 10 seconds.


N.G.

O.K.




SEF248F

SEF913J




SEF320K



(Connect CHK and IGN terminals with a suitable harness)


EEF007



SEF621K

F


E



*: E.C.U. may be the cause of a problem, but this is rarely the case.

FOR MODELS WITHOUT CATALYZER

Checking and adjusting idle rpm and ignition timing



T.D.C.
(Yellow)

10° B.T.D.C. (White)

20° B.T.D.C. (White)



SEF946L

Adjust ignition timing to the specified value by turning distributor after loosening bolts which secure distributor.

10° B.T.D.C.



SEF580K

Check idle speed.



- Read idle speed in "IGN TIMING ADJ" in "WORK SUPPORT" mode.

OR



- Check idle speed.


675 ± 50 rpm

O.K.


Race engine (2,000 - 3,000 rpm) 2 or 3 times under no-load and run engine at idle speed.

Adjust idle speed by turning idle speed adjusting screw.

675 rpm



EEF025



SEF913J



1) Touch "BACK"

OR




- Turn off engine and connect throttle sensor harness connector.
- Start engine.

Race engine (2,000 - 3,000 rpm) 2 or 3 times under no-load and run engine at idle speed.


J


MONITOR	FAIL
CAS-APM-REF	625r/min
RECORD	

SEF135K



Checking and adjusting mixture ratio [With "CO"-meter]





[Without "CO"-meter]



SMA957A




SEF706K




EEF008




SEF707K



SEF708K









Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	EF & EC-216
Self-diagnosis	EF & EC-220
Self-diagnosis — Mode I	EF & EC-222
Self-diagnosis — Mode II (Self-diagnostic results)	EF & EC-222
Self-diagnosis — Mode II (Exhaust gas sensor monitor — Models with catalyzer only)	EF & EC-225
Consult	EF & EC-226
Diagnostic Procedure	EF & EC-232
Basic Inspection	EF & EC-234
Diagnostic Procedure 1 — High Idling after Warm-up	EF & EC-237
Diagnostic Procedure 2 — Hunting	EF & EC-238
Diagnostic Procedure 3 — Unstable Idle	EF & EC-240
Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold	EF & EC-243
Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot	EF & EC-245
Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions	EF & EC-246
Diagnostic Procedure 7 — Hesitation when the Engine is Hot	EF & EC-248
Diagnostic Procedure 8 — Hesitation when the Engine is Cold	EF & EC-248
Diagnostic Procedure 9 — Hesitation under Normal Conditions	EF & EC-249
Diagnostic Procedure 10 — Engine Stalls when turning	EF & EC-250
Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot	EF & EC-252
Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold	EF & EC-254
Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily	EF & EC-256
Diagnostic Procedure 14 — Engine Stalls after Decelerating	EF & EC-258
Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed	EF & EC-262
Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy	EF & EC-264
Diagnostic Procedure 17 — Lack of Power and Stumble	EF & EC-266
Diagnostic Procedure 18 — Detonation	EF & EC-267
Diagnostic Procedure 19 — Surge	EF & EC-269
Diagnostic Procedure 20 — Backfire through the Intake	EF & EC-270
Diagnostic Procedure 21 — Backfire through the Exhaust	EF & EC-270
Diagnostic Procedure 22 MAIN POWER SUPPLY AND GROUND CIRCUIT	EF & EC-271
Diagnostic Procedure 23 CRANK ANGLE SENSOR	EF & EC-273
Diagnostic Procedure 24 AIR FLOW METER	EF & EC-277
Diagnostic Procedure 25 ENGINE TEMPERATURE SENSOR	EF & EC-280
Diagnostic Procedure 26 IGNITION SIGNAL	EF & EC-283
Diagnostic Procedure 27 THROTTLE SENSOR	EF & EC-287
Diagnostic Procedure 28 VEHICLE SPEED SENSOR	EF & EC-290
Diagnostic Procedure 29 START SIGNAL	EF & EC-292
Diagnostic Procedure 30 EXHAUST GAS SENSOR	EF & EC-294
Diagnostic Procedure 31 E.G.R. CONTROL	EF & EC-297
Diagnostic Procedure 32 INJECTOR	EF & EC-300
Diagnostic Procedure 33 FUELPUMP	EF & EC-302
Diagnostic Procedure 34 AIR REGULATOR	EF & EC-306

Contents (Cont'd)

Diagnostic Procedure 35	
A.C.C. VALVE	EF & EC-308
Diagnostic Procedure 36	
RADIATOR FAN CONTROL	EF & EC-311
Diagnostic Procedure 37	
POWER STEERING OIL PRESSURE SWITCH	EF & EC-318
Diagnostic Procedure 38	
NEUTRAL SWITCH	EF & EC-321
Electrical Components Inspection	EF & EC-324





How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The engine has an electronic control unit to control major systems such as fuel control, ignition control, idle speed control, etc. The control unit accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the problems, so a road test with a circuit tester connected to a suspected circuit should be performed.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a driveability complaint. The customer is a very good supplier of information on such problems, especially intermittent ones. Through interaction with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot driveability problems on an electronically controlled engine vehicle.

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



*1: If the self-diagnosis cannot be performed, check main power supply and ground circuit. (See Diagnostic Procedure 22.)

*2: If the trouble is not duplicated, see INTERMITTENT PROBLEM SIMULATION (EF & EC-219).



How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)


INTERMITTENT PROBLEM SIMULATION

In order to duplicate an intermittent problem, it is effective to create similar conditions for component parts, under which the problem might occur.

Perform the activity listed under Service procedure and note the result.

	Variable factor	Influential part	Target condition	Service procedure
1	Mixture ratio	Pressure regulator	Made lean	Remove vacuum hose and apply vacuum.
			Made rich	Remove vacuum hose and apply pressure.
2	Ignition timing	Crank angle sensor	Advanced	Rotate distributor clockwise.
			Retarded	Rotate distributor counterclockwise.
3*	Mixture ratio feedback control	Exhaust gas sensor	Suspended	Disconnect exhaust gas sensor harness connector.
		Control unit	Operation check	Perform self-diagnosis (Mode II) at 2,000 rpm.
4	Idle speed	A.A.C. valve	Raised	Turn idle adjusting screw counterclockwise.
			Lowered	Turn idle adjusting screw clockwise.
5	Electrical connection (Electric continuity)	Harness connectors and wires	Poor electrical connection or improper wiring	Tap or wiggle. Race engine rapidly. See if the torque reaction of the engine unit causes electric breaks.
6	Temperature	Control unit	Cooled	Cool with an icing spray or similar device.
			Warmed	Heat with a hair drier. [WARNING: Do not overheat the unit.]
7	Moisture	Electric parts	Damp	Wet. [WARNING: Do not directly pour water on components. Use a mist sprayer.]
8	Electric loads	Load switches	Loaded	Turn on headlamps, air conditioner, rear defogger, etc.
9	Idle switch condition	Control unit	ON-OFF switching	Rotate throttle sensor body.
10	Ignition spark	Timing light	Spark power check	Try to flash timing light for each cylinder using ignition coil adapter.


*: Models with catalyzer only



Self-diagnosis

CHECK ENGINE LIGHT



A check engine light has been adopted on all models. This light blinks simultaneously with the RED L.E.D. on the E.C.U.



E.C.U. L.E.D.


The E.C.U. is situated behind the glove box, and only has one RED L.E.D.

SELF-DIAGNOSTIC FUNCTION

Mode		Mode I	Mode II
Condition			
Ignition switch in "ON" position	Engine stopped 	BULB CHECK	SELF-DIAGNOSTIC RESULTS
	Engine running 	MALFUNCTION WARNING	EXHAUST GAS SENSOR MONITOR*

*: Models with catalyzer only

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)
HOW TO SWITCH MODES

*: Models with catalyzer only

- Switching the modes is not possible when the engine is running.
- When the ignition switch is turned off during diagnosis in each mode, and then turned back on again after power to the E.C.U. has dropped off completely, the diagnosis will automatically return to Mode I.

Self-diagnosis — Mode I

MODE I — BULB CHECK

In this mode, the RED L.E.D. in the E.C.U. and the CHECK ENGINE LIGHT in the instrument panel stay "ON".

If either remain "OFF", check the bulb in the CHECK ENGINE LIGHT or the RED L.E.D.

MODE I — MALFUNCTION WARNING


CHECK ENGINE LIGHT and RED L.E.D.	Condition
ON	When the E.C.U.'s C.P.U. is malfunctioning.
OFF	O.K.

- The RED L.E.D. and the CHECK ENGINE LIGHT will turn off when normal condition is detected.

Self-diagnosis — Mode II (Self-diagnostic results)

DESCRIPTION

In this mode, a malfunction code is indicated by the number of flashes from the RED L.E.D. or the CHECK ENGINE LIGHT as shown below:



Long (0.6 second) blinking indicates the number of ten digits and short (0.3 second) blinking indicates the number of single digits.

For example, the red L.E.D. flashes once for 0.6 seconds and then it flashes twice for 0.3 seconds. This indicates the number "12" and refers to a malfunction in the air flow meter. In this way, all the problems are classified by their code numbers.

Display code table

Code No.	Detected items
11*	Crank angle sensor circuit
12	Air flow meter circuit
13	Engine temperature sensor circuit
14	Vehicle speed sensor circuit
21*	Ignition signal circuit
43	Throttle sensor circuit
55	No malfunction in the above circuits

*: Check items causing a malfunction of crank angle sensor circuit first, if both code No. 11 and 21 are displayed at the same time.

Self-diagnosis — Mode II (Self-diagnostic results) (Cont'd)

Code No.	Detected items	Malfunction is detected when ...	Check item (remedy)
*11	Crank angle sensor circuit	<ul style="list-style-type: none"> Either 1° or 180° signal is not entered for the first few seconds during engine cranking. Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> Harness and connector (If harness and connector are normal, replace crank angle sensor.)
12	Air flow meter circuit	<ul style="list-style-type: none"> The air flow meter circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector (If harness and connector are normal, replace air flow meter.)
13	Engine temperature sensor circuit	<ul style="list-style-type: none"> The engine temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector Engine temperature sensor
14	Vehicle speed sensor circuit	<ul style="list-style-type: none"> The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> Harness and connector Vehicle speed sensor (reed switch)
*21	Ignition signal circuit	<ul style="list-style-type: none"> The ignition signal in the primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> Harness and connector Power transistor unit
43	Throttle sensor circuit	<ul style="list-style-type: none"> The throttle sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> Harness and connector Throttle sensor


*: Check items causing a malfunction of crank angle sensor circuit first, if both code No. 11 and 21 come out at the same time.

Self-diagnosis — Mode II (Self-diagnostic results) (Cont'd)

RETENTION OF DIAGNOSTIC RESULTS

The diagnostic results will remain in E.C.U. memory until the starter is operated fifty times after a diagnostic item has been judged to be malfunctioning. The diagnostic result will then be canceled automatically. If a diagnostic item which has been judged to be malfunctioning and stored in memory is again judged to be malfunctioning before the starter is operated fifty times, the second result will replace the previous one. It will be stored in E.C.U. memory until the starter is operated fifty times more.

RETENTION TERM CHART (Example)



If the same diagnostic item is judged to be malfunctioning before the starter is operated fifty times, it will be stored in E.C.U. memory until the starter is operated fifty times from this point in time.



: Retention term



: Malfunction detecting point

SEF793D

HOW TO ERASE SELF-DIAGNOSTIC RESULTS

The malfunction code is erased from the backup memory on the E.C.U. when the diagnostic mode is changed from Mode II to Mode I. (Refer to "HOW TO SWITCH MODES".)

- When the battery terminal is disconnected, the malfunction code will be lost from the backup memory within 24 hours.
- Do not erase the stored memory before beginning self-diagnosis.

Self-diagnosis — Mode II (Exhaust gas sensor monitor — Models with catalyzer only)

DESCRIPTION






In this mode, the CHECK ENGINE LIGHT and RED L.E.D. display the condition of the fuel mixture (lean or rich) which is monitored by the exhaust gas sensor.

CHECK ENGINE LIGHT and RED L.E.D.	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop control
OFF	Rich	
★Remains ON or OFF	Any condition	Open loop control

★: Maintains conditions just before switching to open loop.

HOW TO CHECK EXHAUST GAS SENSOR

1. Set Mode II. (Refer to "HOW TO SWITCH MODES".)
2. Start engine and warm it up until engine coolant temperature indicator points to the middle of the gauge.
3. Run engine at about 2,000 rpm for about 2 minutes under no-load conditions.
4. Make sure RED L.E.D. or CHECK ENGINE LIGHT goes ON and OFF more than 5 times every 10 seconds; measured at 2,000 rpm under no-load.



Consult

CONSULT INSPECTION PROCEDURE

1. Turn off ignition switch.
2. Connect "CONSULT" to diagnostic connector.
(Diagnostic connector is located behind the fuse box cover.)

3. Turn on ignition switch.
4. Touch "START".

5. Touch "ENGINE".

6. Perform each diagnostic mode according to the inspection sheet as follows:

For further information, see the CONSULT Operation Manual.

Consult (Cont'd)

E.C.C.S. COMPONENT PARTS APPLICATION

MODE		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST	FUNCTION TEST
E.C.C.S. COMPONENT PARTS						
INPUT	Crank angle sensor		X	X		
	Air flow meter		X	X		
	Engine temperature sensor		X	X	X	
	Exhaust gas sensor★			X★		X
	Vehicle speed sensor			X		X
	Throttle sensor	X	X	X		X
	Exhaust gas temperature sensor★			X★		
	Ignition switch (start signal)			X		X
	Air conditioner switch			X		
	Neutral switch			X		X
	Power steering oil pressure switch			X		X
	Battery			X		
	Injector			X	X	X
OUT-PUT	Power transistor (Ignition signal)	X (Ignition timing)	X (Ignition timing)	X	X (Ignition timing)	X
	A.A.C. valve	X		X	X	X
	E.G.R. & canister control solenoid valve			X	X	
	Air conditioner relay			X		
	Fuel pump relay	X		X	X	X
	Radiator fan			X	X	X

X: Applicable

★: Models with catalyzer only

FUNCTION

Diagnostic mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the control unit can be read.
Active test	Mode in which CONSULT drives some actuators apart from the control units and also shifts some parameters in a specified range.
E.C.U. part numbers	E.C.U. part numbers can be read.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".

Consult (Cont'd)

WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THROTTLE SENSOR ADJUSTMENT	CHECK THE THROTTLE SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● IGN SW "ON" ● ENG NOT RUNNING ● ACC PEDAL NOT PRESSED 	When adjusting throttle sensor initial position.
IGNITION TIMING ADJUSTMENT	<ul style="list-style-type: none"> ● IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANK ANGLE SENSOR. 	When adjusting initial ignition timing.
AAC VALVE ADJUSTMENT	SET ENGINE RPM AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. <ul style="list-style-type: none"> ● ENGINE WARMED UP ● NO-LOAD 	When adjusting idle speed.
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line.

SELF-DIAGNOSTIC RESULTS MODE

DIAGNOSTIC ITEM	DIAGNOSTIC ITEM IS DETECTED WHEN ...	CHECK ITEM (REMEDY)
CRANK ANGLE SENSOR*	<ul style="list-style-type: none"> ● Either 1° or 180° signal is not entered for the first few seconds during engine cranking. ● Either 1° or 180° signal is not input often enough while the engine speed is higher than the specified rpm. 	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace crank angle sensor.)
AIR FLOW METER	<ul style="list-style-type: none"> ● The air flow meter circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector (If harness and connector are normal, replace air flow meter.)
ENGINE TEMP SENSOR	<ul style="list-style-type: none"> ● The engine temperature sensor circuit is open or shorted. (An abnormally high or low output voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Engine temperature sensor
VEHICLE SPEED SENSOR	<ul style="list-style-type: none"> ● The vehicle speed sensor circuit is open or shorted. 	<ul style="list-style-type: none"> ● Harness and connector ● Vehicle speed sensor
IGN SIGNAL-PRIMARY*	<ul style="list-style-type: none"> ● The ignition signal in primary circuit is not entered during engine cranking or running. 	<ul style="list-style-type: none"> ● Harness and connector ● Power transistor unit
THROTTLE SENSOR	<ul style="list-style-type: none"> ● The throttle sensor circuit is open or shorted. (An abnormally high or low voltage is entered.) 	<ul style="list-style-type: none"> ● Harness and connector ● Throttle sensor

*: Check items causing a malfunction of crank angle sensor circuit first, if both "CRANK ANGLE SENSOR" and "IGN SIGNAL-PRIMARY" come out at the same time.

Consult (Cont'd)

DATA MONITOR MODE

Remarks:

- The monitor item marked ★ is applicable to vehicles with catalyzer.
 - Specification data are reference values.
 - Specification data are output/input values which are detected or supplied by the E.C.U. at the connector.
 - * Specification data may not be directly related to their components signals/values/operations.
- i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the E.C.U. according to the signals input from the crank angle sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
CAS, RPM (REF)	<ul style="list-style-type: none">● Tachometer: Connect● Run engine and compare tachometer indication with the CONSULT value.		Almost the same speed as the CONSULT value.	<ul style="list-style-type: none">● Harness and connector● Crank angle sensor
AIR FLOW MTR	<ul style="list-style-type: none">● Engine: After warming up, idle the engine● A/C switch "OFF"● Shift lever "N"	Idle	0.7 - 1.1V	<ul style="list-style-type: none">● Harness and connector● Air flow meter
		2,000 rpm	1.0 - 1.5V	
ENG TEMP SEN	<ul style="list-style-type: none">● Engine: After warming up		More than 70°C (158°F)	<ul style="list-style-type: none">● Harness and connector● Engine temperature sensor
EXH GAS SEN★	<ul style="list-style-type: none">● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ 0.6 - 1.0V	<ul style="list-style-type: none">● Harness and connector● Exhaust gas sensor● Intake air leaks● Injectors
M/R F/C MNT★			LEAN ↔ RICH Changes more than 5 times during 10 seconds.	
CAR SPEED SEN	<ul style="list-style-type: none">● Turn drive wheels and compare speedometer indication with the CONSULT value		Almost the same speed as the CONSULT value	<ul style="list-style-type: none">● Harness and connector● Vehicle speed sensor
BATTERY VOLT	<ul style="list-style-type: none">● Ignition switch: ON (Engine stopped)		11 - 14V	<ul style="list-style-type: none">● Battery● E.C.U. power supply circuit
THROTTLE SEN	<ul style="list-style-type: none">● Ignition switch: ON (Engine stopped)	Throttle valve fully closed	Approx. 0.5V	<ul style="list-style-type: none">● Harness and connector● Throttle sensor● Throttle sensor adjustment
		Throttle valve fully opened	Approx. 5.0V	
START SIGNAL	<ul style="list-style-type: none">● Ignition switch: ON → START		OFF → ON	<ul style="list-style-type: none">● Harness and connector● Starter switch
IDLE POSITION	<ul style="list-style-type: none">● Ignition switch: ON (Engine stopped)	Throttle valve: Idle position	ON	<ul style="list-style-type: none">● Harness and connector● Throttle sensor● Throttle sensor adjustment
		Throttle valve: Slightly open	OFF	
AIR COND SIG	<ul style="list-style-type: none">● Engine: After warming up, idle the engine	A/C switch "OFF"	OFF	<ul style="list-style-type: none">● Harness and connector● Air conditioner switch
		A/C switch "ON"	ON	
NEUTRAL SW	<ul style="list-style-type: none">● Ignition switch: ON	Shift lever in neutral	ON	<ul style="list-style-type: none">● Harness and connector● Neutral switch
		Except above	OFF	
PW/ST SIGNAL	<ul style="list-style-type: none">● Engine: After warming up, idle the engine	Steering wheel in neutral (forward direction)	OFF	<ul style="list-style-type: none">● Harness and connector● Power steering oil pressure switch
		The steering wheel is turned	ON	
FUEL PUMP RLY	<ul style="list-style-type: none">● Ignition switch is turned to ON (Operates for 5 seconds)● Engine running and cranking● When engine is stopped (stops in 1.0 seconds)		ON	<ul style="list-style-type: none">● Harness and connector● Fuel pump relay
	Except as shown above		OFF	
RADIATOR FAN	<ul style="list-style-type: none">● After warming up engine, idle the engine.● A/C switch "OFF"	Engine temperature is 99°C (210°F) or less	OFF	<ul style="list-style-type: none">● Harness and connector● Radiator fan relay● Radiator fan
		Engine temperature is 100°C (212°F) or more	ON	
INJ PULSE	<ul style="list-style-type: none">● Engine: After warming up● A/C switch "OFF"● Shift lever "N"● No-load	Idle	2.5 - 3.3 msec.	<ul style="list-style-type: none">● Harness and connector● Injector● Air flow meter● Intake air system
		2,000 rpm	2.5 - 3.3 msec.	

Consult (Cont'd)


MONITOR ITEM	CONDITION		SPECIFICATION	CHECK ITEM WHEN OUTSIDE SPEC.
IGN TIMING	ditto	Idle	10° B.T.D.C.	<ul style="list-style-type: none"> ● Harness and connector ● Crank angle sensor
		2,000 rpm	More than 20° B.T.D.C.	
AAC VALVE	ditto	Idle	20 - 40%	<ul style="list-style-type: none"> ● Harness and connector ● A.A.C. valve
		2,000 rpm	—	
A/F ALPHA	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	75 - 125%	<ul style="list-style-type: none"> ● Harness and connector ● Injectors ● Air flow meter ● Exhaust gas sensor ● Canister purge line ● Intake air system
AIR COND RLY	<ul style="list-style-type: none"> ● Air conditioner switch OFF → ON 		OFF → ON	<ul style="list-style-type: none"> ● Harness and connector ● Air conditioner switch ● Air conditioner relay
EGR CONT S/V**	<ul style="list-style-type: none"> ● Engine: After warming up ● A/C switch "OFF" ● Shift lever "N" ● No-load 	Idle	ON	<ul style="list-style-type: none"> ● Harness and connector ● E.G.R. & canister control solenoid valve
		2,000 rpm	OFF	

Consult (Cont'd)

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGMENT	CHECK ITEM (REMEDY)
FUEL INJECTION TEST	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Fuel injectors Exhaust gas sensor
AAC/V OPENING TEST	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. Change the AAC valve opening percent using CONSULT. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connector AAC valve
ENGINE TEMP TEST	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connector Engine temperature sensor Fuel injectors
IGN TIMING TEST	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Adjust initial ignition timing
EGR CONT SOL/V TEST*	<ul style="list-style-type: none"> Ignition switch: ON Turn solenoid valve "ON" and "OFF" with the CONSULT and listen to operating sound. 	Each solenoid valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector Solenoid valve
RADIATOR FAN TEST	<ul style="list-style-type: none"> Ignition switch: ON Turn the radiator fan "ON" and "OFF" using CONSULT. 	Radiator fan moves and stops.	<ul style="list-style-type: none"> Harness and connector Radiator fan motor
FUEL PUMP RLY TEST	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connector Fuel pump relay
SELF-LEARN CONT TEST*	<ul style="list-style-type: none"> In this test, the coefficient of self-learning control mixture ratio returns to the original coefficient by touching "CLEAR" on the screen. 		


Remarks: The monitor item marked * is applicable to vehicles with catalyzer only.




Diagnostic Procedure

CAUTION:


1. Before connecting or disconnecting the E.C.U. harness connector to or from any E.C.U., be sure to turn the ignition switch to the "OFF" position and disconnect the negative battery terminal in order not to damage E.C.U. as battery voltage is applied to E.C.U. even if ignition switch is turned off. Failure to do so may damage the E.C.U.




2. When connecting E.C.U. harness connector, tighten securing bolt until red projection is in line with connector face.



3. When connecting or disconnecting pin connectors into or from E.C.U., take care not to damage pin terminals (bend or break).
4. Make sure that there are not any bends or breaks on E.C.U. pin terminal, when connecting pin connectors.



5. Before replacing E.C.U., perform E.C.U. input/output signal inspection and make sure whether E.C.U. functions properly or not. (See page EF & EC-324.)





6. After performing this "Diagnostic Procedure", perform E.C.C.S. self-diagnosis and driving test.

Diagnostic Procedure (Cont'd)

7. When measuring E.C.U. controlled components supply voltage with a circuit tester, separate one tester probe from the other.

If the two tester probes accidentally make contact with each other during measurement, the circuit will be shorted, resulting in damage to the control unit power transistor.






Basic Inspection

1

BEFORE STARTING


1. Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for proper connections
 - Vacuum hoses for splits, kinks, and proper connections
 - Wiring for proper connections, pinches, and cuts



2

CONNECT CONSULT TO THE VEHICLE

Connect "CONSULT" to the diagnostic connector and select "ENGINE" from the menu. (Refer to page EF & EC-226.)




3

DOES ENGINE START?

No → Go to 6

Yes



4

CHECK IGNITION TIMING.

Warm up engine sufficiently and check ignition timing at idle using timing light. (Models with catalyzer: Refer to page 199. Models without catalyzer: Refer to page 207.)


Ignition timing:
 $10^{\circ} \pm 2^{\circ}$ B.T.D.C.

N.G.

Adjust ignition timing by turning crank angle sensor.




O.K.

(Go to (A) on next page.)



TROUBLE DIAGNOSES

Basic Inspection (Cont'd)



5

CHECK IDLE ADJ. SCREW INITIAL SET RPM.



1. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.
2. When touching "START", does engine rpm fall to 675 ± 50 rpm (in "N" position)?

OR



- When disconnecting throttle sensor harness connector, does engine rpm fall to 675 ± 50 rpm (in "N" position)?

No

Adjust engine rpm by turning idle adjusting screw.

Yes

6

CHECK THROTTLE SENSOR IDLE POSITION.



1. Perform "THROTTLE SEN. ADJ" in "WORK SUPPORT" mode.
2. Check that output voltage of throttle sensor is 0.45 to 0.55V. (Throttle valve fully closes.) and "IDLE POSITION" stays "ON".

OR



- Measure output voltage of throttle sensor using voltmeter, and check that it is 0.45 to 0.55V. (Throttle valve fully closed.)

N.G.

1. Adjust output voltage by rotating throttle sensor body.
2. Disconnect throttle sensor harness connector for a few seconds and then reconnect it.
3. Confirm that "IDLE POSITION" stays "ON".

O.K.

(Go to ② on next page.)

Basic Inspection (Cont'd)


7

☆ MONITOR ☆ NO FAIL ☐

START SIGNAL OFF
IDLE POSITION ON
AIR COND SIG OFF
NEUTRAL SW ON

RECORD

SEF384J




8

■ SELF-DIAG RESULTS ■ ☐

FAILURE DETECTED TIME
ENGINE TEMP SENSOR 0

ERASE PRINT

SEF151I



7

CHECK SWITCH INPUT SIGNAL.

Select the following switches in "DATA MONITOR" mode,

- Start signal,
- Idle position,
- Air conditioner signal,
- Neutral (Parking) switch,

and check the switches' ON-OFF operation.

OR

Remove E.C.U. from behind glove box and check the above switches ON-OFF operation using voltmeter at each E.C.U. terminal.

Switch	Condition	Voltage (V)
Start signal	IGN ON → IGN START	0 → Battery voltage
Idle position	—	—
A/C signal	A/C OFF → A/C ON (Engine running)	Battery voltage → 0 - 0.3
Neutral (Parking switch)	Shift lever is Neutral position → Except Neutral position	0 → Battery voltage

O.K.

8

READ SELF-DIAGNOSTIC RESULTS.

- Perform "SELF-DIAG RESULTS" mode.
- Read out self-diagnostic results.
- Is a failure detected?

OR

- Set "Self-diagnostic results mode" in Mode II. (Refer to page EF & EC-222.)
- Count the number of RED L.E.D. or check engine light flashes and read out the codes.
- Are the codes shown?


No

INSPECTION END

N.G. Repair or replace the malfunctioning switch or its circuit.

Yes Go to the relevant inspection procedure.

Diagnostic Procedure 1 — High Idling after Warm-up



1

CHECK AIR REGULATOR.

When pinching the air regulator hose, does the engine speed drop?

Yes

Check air regulator and circuit.
(See page EF & EC-306.)

No

2

CHECK INTAKE AIR LEAK. (MODELS WITH CATALYZER ONLY)



1. Select "SELF-LEARNING CONT" in "ACTIVE TEST" mode.
2. Clear the self-learning control coefficient by touching "CLEAR".
3. Does the engine speed drop?

OR



1. Disconnect exhaust gas sensor harness connector.
2. After racing engine at 2,000 rpm under no-load for about 30 seconds, does the engine speed drop?

Yes

Discover air leak location and repair.

No

3

CHECK THROTTLE LINKAGE.



1. Check that throttle linkage moves smoothly.
2. Confirm that throttle valve both fully opens and fully closes.

N.G.


Repair throttle linkage or sticking of throttle valve.

O.K.

INSPECTION END



Diagnostic Procedure 2 — Hunting




1

CHECK EXHAUST GAS SENSOR.
(MODELS WITH CATALYZER ONLY)
When disconnecting exhaust gas sensor harness connector, is the hunting fixed?

Yes → Check exhaust gas sensor. (See page EF & EC-294.)

No



2

PERFORM POWER BALANCE TEST.


1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR

- When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **4**.

Yes




3

CHECK SPARK PLUGS.
Remove the spark plugs and check for fouling, etc.



N.G. → Repair or replace spark plug(s).

O.K.

(Go to **A** on next page.)



Diagnostic Procedure 2 — Hunting (Cont'd)



4

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes

Discover air leak location and repair.

No

5

CHECK E.G.R. CONTROL VALVE.

Check E.G.R. control valve for sticking.

N.G.







Repair or replace.

O.K.


INSPECTION END

TROUBLE DIAGNOSES

Diagnostic Procedure 3 — Unstable Idle




Diagnostic Procedure 3 — Unstable Idle (Cont'd)



5
CHECK SPARK PLUGS.
Remove the spark plugs and check for fouling, etc.

N.G. → Repair or replace spark plug(s).

O.K. →



6
CHECK FUEL PRESSURE.
1. Release fuel pressure to zero. (Refer to page EF & EC-324.)
2. Install fuel pressure gauge and check fuel pressure.
At idle:
Approx. 245 kPa
(2.45 bar, 2.5 kg/cm², 36 psi)


N.G. → Check fuel pump and circuit.

O.K. →



7
CHECK EXHAUST GAS SENSOR.
(MODELS WITH CATALYZER ONLY)
1. See "M/R F/C MNT" in "Data monitor" mode.
2. Maintaining engine at 2,000 rpm under no-load (engine is warmed up sufficiently), check that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.
RICH → LEAN → RICH →
1 time 2 times
LEAN → RICH.....
OR

N.G. → Replace exhaust gas sensor.








1. Set "Exhaust gas sensor monitor" in the self-diagnostic Mode II. (See page EF & EC-222.)
2. Maintaining engine at 2,000 rpm under no-load, check to make sure that the RED L.E.D. on the E.C.U. or the check engine light on the instrument panel goes ON and OFF more than 5 times during 10 seconds.

O.K. →


(Go to **B** on next page.)

Diagnostic Procedure 3 — Unstable Idle (Cont'd)



★: E.C.U. may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold




1

CHECK BATTERY AND STARTER.
Check battery and starter condition.
(Refer to EL section.)

N.G. Repair or replace.

O.K.




2

CHECK FUEL PRESSURE.

1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?

No Check fuel pump and circuit. (See page EF & EC-302.)

Yes




3

CHECK AIR REGULATOR AND A.A.C. VALVE.

When pressing accelerator pedal fully, can you start the engine.

Yes Check A.A.C. valve, air regulator and circuits. (See pages EF & EC-306.)

No




4

CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Turn ignition switch ON. (Do not start engine.)
3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No Check injector(s) and circuit(s).

Yes



5

CHECK IGNITION SPARK.


1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G. Check ignition coil, power transistor unit and their circuits. (See page EF & EC-283.)

O.K.

(Go to **A** on next page.)

Diagnostic Procedure 4 — Hard to Start or Impossible to Start when the Engine is Cold (Cont'd)



6

CHECK SPARK PLUGS.

Remove the spark plugs and check for fouling, etc.

N.G.

Repair or replace spark plug(s).

O.K.

7

CHECK E.C.U. HARNESS CONNECTOR.

Check the E.C.U. pin terminals for damage or poor connection of E.C.U. harness connector.

N.G.

Repair or replace.

O.K.

8

CHECK E.C.U. POWER SUPPLY AND GROUND CIRCUIT.

Refer to page EF & EC-271.

N.G.

Repair or replace.

O.K.

9

TRY A KNOWN GOOD E.C.U.*

Trouble is fixed.


Replace E.C.U.

Trouble is not fixed.

INSPECTION END

★: E.C.U. may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 5 — Hard to Start or Impossible to Start when the Engine is Hot



1

CHECK FUEL PRESSURE.

1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?

No

Check fuel pump and circuit. (See page EF & EC-302.)

Yes

2

CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Can you start engine?

Yes

Check fuel properties.

No

3

CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Turn ignition switch ON. (Do not start engine.)
3. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No

Check injector(s) and circuit(s).

Yes

4

CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G.

Check ignition coil, power transistor and circuits. (See page EF & EC-283.)

O.K.

5

CHECK E.C.U. HARNESS CONNECTOR.

Check the E.C.U. pin terminals for damage or poor connection of E.C.U. harness connector.

N.G.

Repair or replace.

O.K.

6

CHECK E.C.U. POWER SUPPLY AND GROUND CIRCUIT.

Refer to page EF & EC-271.

N.G.

Repair or replace.

O.K.

7

TRY A KNOWN GOOD E.C.U.*




Trouble is fixed.

Replace E.C.U.


Trouble is not fixed.

INSPECTION END

*: E.C.U. may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions




1

CHECK BATTERY AND STARTER.
Check battery and starter operation.
(Refer to EL section.)

N.G. Repair or replace.

O.K.




2

CHECK FUEL PRESSURE.

1. Pinch fuel feed hose with fingers.
2. When cranking the engine, is there any pressure on the fuel feed hose?

No Check fuel pump and circuit. (See page EF & EC-302.)

Yes



3

CHECK INJECTOR FOR LEAKAGE.

When pressing accelerator pedal fully, can you start the engine.

Yes Check injector(s) for leakage.

No


4

CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No Check injectors and circuits.

Yes



4


CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G. Check ignition coil, power transistor unit and circuits. (See page EF & EC-283.)

O.K.

(Go to A on next page.)






5


Ignition wire

Spark plug

Diagnostic Procedure 6 — Hard to Start or Impossible to Start under Normal Conditions (Cont'd)



★: E.C.U. may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 7 — Hesitation when the Engine is Hot

1

CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes

Check fuel properties.

No

2

CHECK CANISTER PURGE. (MODELS WITH CATALYZER ONLY)

1. Disconnect canister purge line hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes

Check purge and vacuum line.

No

3

CHECK FOR INTAKE AIR LEAK.



When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes

Discover air leak location and repair.

No

INSPECTION END



Diagnostic Procedure 8 — Hesitation when the Engine is Cold

1

CHECK SPARK PLUGS.

Remove spark plugs and check for fouling, etc.

N.G.

Repair or replace spark plug(s).

O.K.

2

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?

Yes

Discover air leak location and repair.

No

Trouble is fixed.

3

TRY A KNOWN GOOD AIR FLOW METER.

Replace air flow meter.



Trouble is not fixed.

4





CHECK FOR INTAKE VALVE DEPOSITS.

If there are deposits on intake valves, remove them.

INSPECTION END



Diagnostic Procedure 9 — Hesitation under Normal Conditions



1

CHECK SPARK PLUGS.

Remove spark plugs and check for fouling, etc.

N.G.

Repair or replace spark plug(s).

O.K.

2

CHECK EXHAUST GAS SENSOR. (MODELS WITH CATALYZER ONLY)



1. See "M/R F/C MNT" in "DATA MONITOR" mode.
2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH → LEAN → RICH →

1 time

2 times

LEAN → RICH.....

OR



1. Set "Exhaust gas sensor monitor" in the self-diagnostic Mode II. (See page EF & EC-222.)
2. Maintaining engine at 2,000 rpm under no-load, check that the RED L.E.D. on the E.C.U. or the check engine light on the instrument panel goes ON and OFF more than 5 times during 10 seconds.

N.G.

Replace exhaust gas sensor.

O.K.

3

CHECK CANISTER PURGE. (MODELS WITH CATALYZER ONLY)

1. Disconnect canister purge line hose and plug hose.
2. Perform cruise test.
3. Does the hesitation disappear?

Yes

Check purge and vacuum line.

No

4

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine speed rise?


Yes

Discover air leak location and repair.

No

INSPECTION END

Diagnostic Procedure 10 — Engine Stalls when Turning



1

CHECK FUEL LEVEL.

Check to see that there is enough fuel in tank.

N.G. Fill fuel tank with fuel.

O.K.

2

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR



When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No Go to 5

Yes

3

CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No Check injector(s) and circuit(s).

Yes

4





CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.



N.G. Check ignition coil, power transistor and circuits. (See page EF & EC-283.)

O.K.

(Go to A on next page.)




Diagnostic Procedure 10 — Engine Stalls when Turning (Cont'd)



★: E.C.U. may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot



1


CHECK FUEL VAPOR.

1. Disconnect fuel pressure regulator vacuum hose and plug hose.
2. Perform cruise test.
3. Does the engine stall disappear?

Yes

Check fuel properties.

No



2

PERFORM POWER BALANCE TEST.



1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR




When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

No

Go to 5.

Yes



3

CHECK INJECTOR.


1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No

Check injector(s) and circuit(s).



Yes

(Go to A on next page.)



TROUBLE DIAGNOSES

Diagnostic Procedure 11 — Engine Stalls when the Engine is Hot (Cont'd)



4

CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G.

Check ignition coil, power transistor and their circuits. (See page EF & EC-283.)

A

O.K.

5

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. (Refer to page EF & EC-324.)
2. Install fuel pressure gauge and check fuel pressure.

N.G.

Check fuel pressure regulator diaphragm.

At idle:

Approx. 245 kPa
(2.45 bar, 2.5 kg/cm², 36 psi)

A few seconds after ignition switch
is turned OFF to ON:

Approx. 294 kPa
(2.94 bar, 3.0 kg/cm², 43 psi)

O.K.

6

CHECK E.C.U. HARNESS CONNECTOR.

Check the E.C.U. pin terminals for damage or poor connection of E.C.U. harness connector.

N.G.

Repair or replace.

O.K.

7

CHECK E.C.U. POWER SUPPLY AND GROUND CIRCUIT.

Refer to page EF & EC-271.

N.G.

Repair or replace.

O.K.

8

TRY A KNOWN GOOD E.C.U.*

Trouble is fixed.


Replace E.C.U.

Trouble is not fixed.

INSPECTION END

*: E.C.U. may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold



1

CHECK AIR REGULATOR AND A.A.C. VALVE.

When the engine is cold, can you start the engine when pressing accelerator pedal fully?

N.G.

Check A.A.C. valve, air regulator and circuit. (See pages EF & EC-306.)

O.K.

2

PERFORM POWER BALANCE TEST.



1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

OR





When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

N.G.

Go to 6.

O.K.



3


CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

N.G.

Check injector(s) and circuit(s).

O.K.



4

CHECK IGNITION SPARK.


1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

N.G.




Check ignition coil, power transistor and circuits. (See page EF & EC-283.)

O.K.






(Go to A on next page.)



Diagnostic Procedure 12 — Engine Stalls when the Engine is Cold (Cont'd)



★: E.C.U. may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily

1**CHECK A.A.C. VALVE.**

1. Select "A.A.C. VALVE OPENING" in "ACTIVE TEST" mode.
2. When touching "Qu" and "Qd", does the engine speed change according to the percent of A.A.C. valve opening?

No

Check A.A.C. valve and circuit. (See page EF & EC-306.)

OR

- When disconnecting A.A.C. valve harness connector, does the engine speed drop?

Yes

2**PERFORM POWER BALANCE TEST.**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No

Go to **5**.

OR

- When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes

3**CHECK INJECTOR.**

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?



No

Check injector(s) and their circuit(s).

Yes

(Go to **A** on next page.)

Diagnostic Procedure 13 — Engine Stalls when Stepping on the Accelerator Momentarily (Cont'd)



- 4**
- CHECK IGNITION SPARK.**
1. Disconnect ignition wire from spark plug.
 2. Connect a known good spark plug to the ignition wire.
 3. Place end of spark plug against an earth point with engine cranking.
 4. Check for spark.

N.G. Check ignition coil, power transistor and their circuits. (See page EF & EC-283.)

- O.K.
- 5**
- CHECK FUEL PRESSURE.**
1. Release fuel pressure to zero. (Refer to page EF & EC-324.)
 2. Install fuel pressure gauge and check fuel pressure.
- At idle:**
- Approx. 245 kPa
(2.45 bar, 2.5 kg/cm², 36 psi)
- A few seconds after ignition switch is turned OFF to ON:**
- Approx. 294 kPa
(2.94 bar, 3.0 kg/cm², 43 psi)

N.G. Check fuel pressure regulator diaphragm.

- O.K.
- 6**
- CHECK E.C.U. HARNESS CONNECTOR.**
- Check the E.C.U. pin terminals for damage or poor connection of E.C.U. harness connector.

N.G. Repair or replace.

- O.K.
- 7**
- CHECK E.C.U. POWER SUPPLY AND GROUND CIRCUIT.**
- Refer to page EF & EC-271.

N.G. Repair or replace.

- O.K.
- 8**
- TRY A KNOWN GOOD E.C.U.★**





Trouble is fixed.
Replace E.C.U.

Trouble is not fixed.

INSPECTION END

★: E.C.U. may be the cause of a problem, but this is rarely the case.

Diagnostic Procedure 14 — Engine Stalls after Decelerating

**1****CHECK A.A.C. VALVE.**

1. Select "A.A.C. VALVE OPENING" in "ACTIVE TEST" mode.
2. When touching "Qu" and "Qd", does the engine speed change according to the percent of A.A.C. valve opening?

No

Check A.A.C. valve and circuit. (See page EF & EC-306.)



OR

When disconnecting A.A.C. valve harness connector, does the engine speed drop?

Yes

2**CHECK IDLE ADJ. SCREW CLOGGING.**

1. Perform "IGN TIMING ADJ" in "WORK SUPPORT" mode.
2. Can you set engine rpm at 675 ± 50 rpm (in "N" position) by turning idle adjusting screw?

No

Check for IAS clogging or throttle chamber clogging.








- OR
1. Disconnect throttle sensor harness connector.
 2. Can you set engine rpm at 675 ± 50 rpm (in "N" position) by turning idle adjusting screw?



Yes

(Go to **A** on next page.)

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)



B

6

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. (Refer to page EF & EC-324.)
2. Install fuel pressure gauge and check fuel pressure.

At idle:

Approx. 245 kPa
(2.45 bar, 2.5 kg/cm², 36 psi)

A few seconds after ignition switch is turned OFF to ON:

Approx. 294 kPa
(2.94 bar, 3.0 kg/cm², 43 psi)

N.G.

Check fuel pressure regulator diaphragm.

O.K.

7

CHECK EXHAUST GAS SENSOR. (MODELS WITH CATALYZER ONLY)

1. See "M/R F/C MNT" in "DATA MONITOR" mode.
2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH → LEAN → RICH →

1 time 2 times

LEAN → RICH.....

OR




1. Set "Exhaust gas sensor monitor" in the self-diagnostic Mode II. (See page EF & EC-222.)
2. Maintaining engine at 2,000 rpm under no-load, check that the RED L.E.D. on the E.C.U. or the check engine light on the instrument panel goes ON and OFF more than 5 times during 10 seconds.

N.G.





Replace exhaust gas sensor.

O.K.

(Go to C on the next page.)

Diagnostic Procedure 14 — Engine Stalls after Decelerating (Cont'd)

*: E.C.U. may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed

1

PERFORM POWER BALANCE TEST.

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No → Go to **4**.

OR



When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes

2

CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No → Check injector(s) and circuit(s).

Yes

3

CHECK IGNITION SPARK.




1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

No → Check ignition coil, power transistor and circuits. (See page EF & EC-283.)

Yes


(Go to **A** on next page.)

Diagnostic Procedure 15 — Engine Stalls when Accelerating or when Driving at Constant Speed (Cont'd)




★: E.C.U. may be the cause of a problem, but this is rarely the case.


Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy




SEF389J




SEF325K



EEF029



SEF717K



SEF282G

1

CHECK BATTERY AND ALTERNATOR.
Check battery and alternator condition.
(Refer to EL section.)

N.G. Repair or replace.

O.K.

2

PERFORM POWER BALANCE TEST.



1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

No Go to 5.

OR



When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes

3

CHECK INJECTOR.

1. Remove distributor from engine. (Crank angle sensor harness connector should remain connected.)
2. Disconnect ignition wires.
3. Turn ignition switch ON. (Do not start engine.)
4. When rotating distributor shaft slowly by hand, does each injector make an operating sound?

No Check injector(s) and circuit(s).

Yes

4

CHECK IGNITION SPARK.

1. Disconnect ignition wire from spark plug.
2. Connect a known good spark plug to the ignition wire.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.


N.G. Check ignition coil, power transistor and circuits. (See page EF & EC-283.)

O.K.

(Go to A on next page.)

TROUBLE DIAGNOSES

Diagnostic Procedure 16 — Engine Stalls when the Electrical Load is Heavy (Cont'd)



5

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. (Refer to page EF & EC-324.)
2. Install fuel pressure gauge and check fuel pressure.

At idle:

Approx. 245 kPa
(2.45 bar, 2.5 kg/cm², 36 psi)

A few seconds after ignition switch is turned OFF to ON:

Approx. 294 kPa
(2.94 bar, 3.0 kg/cm², 43 psi)

N.G. Check fuel pressure regulator diaphragm.

A

O.K.

6

CHECK E.C.U. HARNESS CONNECTOR.

Check the E.C.U. pin terminals for damage or poor connection of E.C.U. harness connector.

N.G. Repair or replace.

O.K.

7

CHECK E.C.U. POWER SUPPLY AND GROUND CIRCUIT.

Refer to page EF & EC-271.

N.G. Repair or replace.

O.K.

8

TRY A KNOWN GOOD E.C.U.★



Trouble is fixed.

Replace E.C.U.

Trouble is not fixed.

INSPECTION END

★: E.C.U. may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 17 — Lack of Power and Stumble

1

CHECK FUEL PRESSURE.

1. Release fuel pressure to zero. (Refer to page EF & EC-324.)
2. Install fuel pressure gauge and check fuel pressure.

At idle:

Approx. 245 kPa
(2.45 bar, 2.5 kg/cm², 36 psi)

A few seconds after ignition switch
is turned OFF to ON:

Approx. 294 kPa
(2.94 bar, 3.0 kg/cm², 43 psi)

N.G.

Check fuel pressure regu-
lator diaphragm.

O.K.

2

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering
the blow-by air supply), does the engine
speed rise?

Yes





Discover air leak location
and repair.

No

INSPECTION END

TROUBLE DIAGNOSES

Diagnostic Procedure 18 — Detonation



1

CHECK FOR INTAKE AIR LEAK.

When pinching blow-by hose (lowering the blow-by air supply), does the engine rpm rise?

Yes

Discover air leak location and repair.

No

2

CHECK E.G.R. OPERATION.

1. Apply vacuum directly to the E.G.R. valve using a handy vacuum pump.
2. Check to see that the engine runs rough or dies.

No

Check E.G.R. valve for sticking.

Yes

3

CHECK E.G.R. & CANISTER CONTROL SOLENOID VALVE.

N.G.

Check solenoid valve and circuit.



1. Select "E.G.R. CONT SOL VALVE" in "ACTIVE TEST" mode.
2. Turn E.G.R. & canister control solenoid valve ON and OFF.
3. Check operating sound.

OR





1. Disconnect E.G.R. & canister control solenoid valve harness connector.
2. Supply E.G.R. & canister control solenoid valve terminals with battery current and check operating sound.

O.K.

(Go to (A) on next page.)

Diagnostic Procedure 18 — Detonation (Cont'd)

**CHECK VACUUM HOSES.**

Check the following vacuum hoses for clogging, cracks and poor connection.

- ① E.G.R. control valve to B.P.T. valve
- ② B.P.T. valve to 3-way connector
- ③ 3-way connector to E.G.R. & canister control solenoid valve
- ④ E.G.R. & canister control solenoid valve to vacuum tube
- ⑤ Vacuum tube to air cleaner
- ⑥ E.G.R. & canister control solenoid valve to lower throttle body

N.G. Repair or replace.

O.K.

5

CHECK FOR OIL LEAK TO COMBUSTION CHAMBER.



Remove spark plugs and check for fouling with oil.

Yes Check pistons, piston rings, valves, valve seats, valve oil seal, engine oil level, etc.

No

INSPECTION END

Diagnostic Procedure 19 — Surge



1

CHECK EXHAUST GAS SENSOR.
(MODELS WITH CATALYZER ONLY)



1. See "M/R F/C MNT" in "DATA MONITOR" mode.
2. Maintaining engine at 2,000 rpm under no-load (with engine warmed up sufficiently.), check to make sure that the monitor fluctuates between "LEAN" and "RICH" more than 5 times during 10 seconds.

RICH → LEAN → RICH →

1 time 2 times

LEAN → RICH.....

OR



1. Set "Exhaust gas sensor monitor" in the self-diagnostic Mode II. (See page EF & EC-222.)
2. Maintaining engine at 2,000 rpm under no-load, check that the RED L.E.D. on the E.C.U. or the check engine light on the instrument panel goes ON and OFF more than 5 times during 10 seconds.

N.G. Replace exhaust gas sensor.

O.K.

2

CHECK E.G.R. CONTROL VALVE.
Check E.G.R. control valve for sticking.

N.G. Repair or replace.

O.K.

3

TRY A KNOWN GOOD E.C.U.*



Trouble is fixed.

Replace E.C.U.


Trouble is not fixed.

INSPECTION END


*: E.C.U. may be the cause of a problem, but this is rarely the case.



Diagnostic Procedure 20 — Backfire through the Intake




Diagnostic Procedure 21 — Backfire through the Exhaust







Diagnostic Procedure 22

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)




Harness layout




TROUBLE DIAGNOSES

Diagnostic Procedure 22 (Cont'd)



Diagnostic Procedure 22 (Cont'd)




E

CHECK VOLTAGE BETWEEN E.C.U. AND GROUND.
 1) Check voltage between E.C.U. terminal (46) and ground.
Voltage: Battery voltage

N.G. Check the following.

- Harness connectors (MR, C103)
- 10A fuse
- Harness continuity between E.C.U. and fusible link

If N.G., repair harness or connectors.




F

CHECK GROUND CIRCUIT.
 1) Check harness continuity between E.C.U. terminals (39), (48) and engine ground.
Continuity should exist.

N.G. Check the following.

- Harness connectors (M39, E1)
- Harness continuity between E.C.U. and engine ground

If N.G., repair harness or connectors.




G

CHECK OUTPUT SIGNAL CIRCUIT.
 1) Check harness continuity between E.C.U. terminal (4) and terminal (2).
Continuity should exist.

N.G. Check the following.

- Harness connectors (M6, C101)
- Harness continuity between E.C.U. and E.C.C.S. relay

If N.G., repair harness or connectors.



H

CHECK INPUT SIGNAL CIRCUIT.
 1) Turn ignition switch "ON".
 2) Check voltage between E.C.U. terminal (36) and ground.
Voltage: Battery voltage

N.G. Check the following.

- Harness connectors (MR, C103)
- Harness continuity between E.C.U. and ignition switch

If N.G., repair harness or connectors.

CHECK COMPONENT (E.C.C.S. relay).
 Refer to "Electrical Components Inspection".
 (See page EF & EC-324.)


N.G. Replace E.C.C.S. relay.

O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.




Diagnostic Procedure 23

CRANK ANGLE SENSOR (Code No. 11)




MEF788C

Harness layout



Diagnostic Procedure 23 (Cont'd)



INSPECTION START

A

CHECK POWER SUPPLY.

- 1) Disconnect crank angle sensor harness connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between terminal (b) and ground.


Voltage: Battery voltage

N.G.

Check the following.

- Harness connectors (C103), (M8)
 - Harness connectors (M39), (E1)
 - Harness continuity between crank angle sensor and E.C.C.S. relay
- If N.G., repair harness or connectors.

O.K.

**B**


CHECK GROUND CIRCUIT.

- 1) Turn ignition switch "OFF".
 - 2) Check harness continuity between terminal (a) and engine ground.
- Continuity should exist.**

N.G.

Repair harness or connectors.

O.K.

**C**

CHECK INPUT SIGNAL CIRCUIT.

- 1) Reconnect crank angle sensor harness connector.
 - 2) Start engine.
 - 3) Read crank angle sensor signals in "DATA MONITOR" mode with CONSULT.
- rpm: 750 ± 50**
- OR

N.G.


Check the following.

- Harness connectors (M39), (E1)
 - Harness continuity between crank angle sensor and E.C.U.
- If N.G., repair harness or connectors.



- 1) Disconnect E.C.U. harness connector.
 - 2) Check harness continuity between terminal (c) and E.C.U. terminals (31), (40) (1° signal), terminal (d) and E.C.U. terminals (22), (30) (180° signal).
- Continuity should exist.**

O.K.



CHECK COMPONENT

(Crank angle sensor).
Refer to "Electrical Components Inspection".
(See page EF & EC-324.)

N.G.


Replace crank angle sensor.

O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.


Diagnostic Procedure 23 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.






Diagnostic Procedure 24



AIR FLOW METER (Code No. 12)



Harness layout



Diagnostic Procedure 24 (Cont'd)



N.G.



Check the following.

- Harness connectors (C103), (M8)

- Harness connectors (M85), (E117) (R.H.D. models)

- Harness continuity between air flow meter and E.C.C.S. relay
- If N.G., repair harness or connectors.

O.K.




N.G.

Check the following.

- Harness connectors (M85), (E117) (R.H.D. models)

- Harness continuity between air flow meter and E.C.U.
- If N.G., repair harness or connectors.

O.K.




N.G.

Check the following.


- Harness connectors (M85), (E117) (R.H.D. models)

- Harness continuity between air flow meter and E.C.U.
- If N.G., repair harness or connectors.

OR



O.K.



N.G.




Replace air flow meter.

O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.


Diagnostic Procedure 24 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.






Diagnostic Procedure 25

ENGINE TEMPERATURE SENSOR (Code No. 13)



Harness layout






Diagnostic Procedure 25 (Cont'd)

A

☆ MONITOR	☆ NO FAIL	<input type="checkbox"/>
ENG TEMP SEN 95°C		


RECORD

SEF825K




Diagnostic Procedure 25 (Cont'd)

Perform FINAL CHECK by the following procedure after repair is completed.



Diagnostic Procedure 26

IGNITION SIGNAL (Code No. 21)







MEF791C



TROUBLE DIAGNOSES

Diagnostic Procedure 26 (Cont'd)

Harness layout





Diagnostic Procedure 26 (Cont'd)



N.G. Check the following.

- Harness connectors (C103, MR)
- Harness connectors (MR5, E117) (R.H.D. models)
- Harness continuity between ignition coil and ignition switch





If N.G., repair harness or connectors.



N.G. Check the following.

- Harness connectors (MR5, E117) (R.H.D. models)
- Harness connectors (MR9, E1)
- Harness continuity between power transistor and engine ground
- Harness continuity between ignition coil and power transistor
- Harness continuity between ignition coil and resistor



If N.G., repair harness or connector.



N.G. Check the following.

- Harness connectors (M141, E119) (R.H.D. models)
- Harness continuity between resistor and E.C.U.

If N.G., repair harness or connector.




N.G. Check the following.

- Harness connectors (M141, E119) (R.H.D. models)
- Harness continuity between power transistor and E.C.U.

If N.G., repair harness or connectors.


A

Diagnostic Procedure 26 (Cont'd)






Diagnostic Procedure 27



THROTTLE SENSOR (Code No. 34)



Harness layout





Diagnostic Procedure 27 (Cont'd)



N.G. Check the following.

- Harness connectors (H39, E1)
- Harness continuity between E.C.U. and throttle sensor



If N.G., repair harness or connectors.



N.G. Check the following.

- Harness connectors (H39, E1)
- Harness continuity between E.C.U. and throttle sensor







If N.G., repair harness or connectors.




N.G. Check the following.

- Harness connectors (H39, E1)
- Harness continuity between E.C.U. and throttle sensor

If N.G., repair harness or connectors.




N.G. Replace throttle sensor.






Diagnostic Procedure 27 (Cont'd)

Perform **FINAL CHECK** by the following procedure after repair is completed.



Diagnostic Procedure 28 (Cont'd)



INSPECTION START

- A**
- CHECK OVERALL FUNCTION**
- 1) Jack up front wheels.
 - 2) Disconnect E.C.U. harness connector.
 - 3) Rotate front wheel by hand.
 - 4) Check harness continuity between E.C.U. terminal ③② and body ground.
- Continuity should come and go.**

O.K. INSPECTION END.

N.G.

CHECK SPEEDOMETER FUNCTION.
Make sure that speedometer functions properly.

N.G. Check vehicle speed sensor and circuit.
(Refer to EL section.)

O.K.

- B**
- CHECK INPUT SIGNAL CIRCUIT.**
- 1) Reconnect E.C.U. harness connector
 - 2) Perform "CAR SPEED SEN CIRCUIT" in "FUNCTION TEST" mode with CONSULT.
- OR
- 2) Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT.
CONSULT value should be the same as the speedometer indication.
- OR
- 1) Turn ignition switch "OFF".
 - 2) Disconnect combination meter harness connector.
 - 3) Check harness continuity between E.C.U. terminal ③② and terminal ① (SLX models), terminal ② (L and LX models).
- Continuity should exist.**


N.G. Repair harness or connectors.

O.K.



Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

Diagnostic Procedure 29

START SIGNAL (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 29 (Cont'd)

A

■ START SIGNAL CKT ■

1. CLOSE THROTTLE, SHIFT TO P OR N RANGE.
2. TOUCH START AND START ENGINE IMMEDIATELY

NEXT START

SEF191L

A

☆ MONITOR ☆ NO FAIL ☐

START SIGNAL	OFF
IDLE POSITION	ON
AIR COND SIG	OFF
NEUTRAL SW	ON

RECORD

SEF384J

A

C/UNIT CONNECTOR

34

V

ST

SEF202K

B

DISCONNECT H.S. CONNECT


C/UNIT CONNECTOR

34

Ω


OFF

MEF760C






Diagnostic Procedure 30







EXHAUST GAS SENSOR (Not self-diagnostic item)




Harness layout



Diagnostic Procedure 30 (Cont'd)



Diagnostic Procedure 30 (Cont'd)

**D**

CHECK INPUT SIGNAL CIRCUIT.

- 1) Check harness continuity between E.C.U. terminal 19 and terminal (b). Continuity should exist.

N.G.

Check the following.

- Harness connectors (M19, E1)
 - Harness continuity between E.C.U. and exhaust gas sensor
- If N.G., repair harness or connectors.

O.K.


Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

O.K.




Replace exhaust gas sensor.

Diagnostic Procedure 31






E.G.R. CONTROL (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 31 (Cont'd)



INSPECTION START

A

CHECK OVERALL FUNCTION.

- 1) Start engine and warm it up sufficiently.
- 2) Perform self-diagnosis.
Make sure that code No. 12 is not displayed.
Make sure that E.C.U.'s C.P.U. is not in "fail-safe" state.
- 3) Make sure that E.G.R. control valve spring moves up and down when racing engine.
(Use your finger.)

Moves up and down

INSPECTION END

does not move up and down

B

CHECK VACUUM SOURCE TO E.G.R. CONTROL VALVE.

- 1) Disconnect vacuum hose to E.G.R. control valve.
- 2) Make sure that vacuum exists under the following conditions.

At idle:

Vacuum should not exist.

Engine speed is about 2,500 rpm:

Vacuum should exist.

O.K.

CHECK COMPONENTS
(E.G.R. control valve and
B.P.T. valve).
Refer to "Electrical Com-
ponents Inspection".
(See page EF & EC-355.)

N.G.

Replace malfunctioning
component(s).

N.G.

C

CHECK CONTROL FUNCTION.

- 1) Check voltage between E.C.U. terminal (105) and ground under the following conditions.

Voltage:

At idle

0 - 1.0V

Engine speed is about 2,500 rpm

Battery voltage

O.K.

CHECK VACUUM HOSE.


- 1) Check vacuum hose for clogging, cracks and proper connection.

N.G.




A

Diagnostic Procedure 31



E.G.R. CONTROL (Not self-diagnostic item)



Harness layout



Diagnostic Procedure 31 (Cont'd)



- E**
- CHECK POWER SUPPLY.**
- 1) Stop engine.
 - 2) Disconnect E.G.R. & canister control solenoid valve harness connector.
 - 3) Turn ignition switch "ON".
 - 4) Check voltage between terminal **(a)** and ground.

Voltage: Battery voltage

- N.G.
- Check the following.
- Harness connectors
 - 10A fuse
 - Harness continuity between E.G.R. & canister control solenoid valve and fuse
- If N.G., repair harness or connectors.

O.K.

- F**
- CHECK OUTPUT SIGNAL CIRCUIT.**
- 1) Turn ignition switch "OFF".
 - 2) Disconnect E.C.U. harness connector.
 - 3) Check harness continuity between E.C.U. terminal **(105)** and terminal **(b)**.
- Continuity should exist.**

- N.G.
- Repair harness or connectors.

O.K.

- G**
- CHECK COMPONENT**
(E.G.R. & canister control solenoid valve).
- 1) Reconnect E.G.R. & canister control solenoid valve harness connector and E.C.U. harness connector.
 - 2) Start engine.
 - 3) Turn E.G.R. & canister control solenoid valve "ON" and "OFF" in "ACTIVE TEST" mode with CONSULT and check operating sound.

OR



Refer to "Electrical Components Inspection".
(See page EF & EC-324).


- N.G.
- Replace E.G.R. & canister control solenoid valve.

O.K.

Check E.C.U. pin terminals for damage or the connection of E.C.U. harness connector.

Diagnostic Procedure 32

INJECTOR (Not self-diagnostic item)



MEF797C

Harness Layout

