
WHEEL AND TYRE

CONTENTS

31109000182

GENERAL INFORMATION	2	ON-VEHICLE SERVICE	4
SERVICE SPECIFICATIONS	2	Tyre Inflation Pressure Check	4
TROUBLESHOOTING	3	Tyre Wear Check	4
		Wheel Runout Check	4
		WHEEL AND TYRE	4



GENERAL INFORMATION

31100010276

The wheels and tyres of the following specifications have been established.

SPECIFICATIONS

31100030135

Items		Specification
Wheel	Type	Steel Aluminium*
	Size	15 × 6JJ
	Amount of wheel offset mm	46
	Pitch circle diameter (P.C.D.) mm	114.3
Tyre	Size	205/65R15 94H
Spare wheel	Type	Steel
	Size	15 x 4.0T, 15 x 6JJ*
	Amount of wheel offset mm	46
	Pitch circle diameter (P.C.D) mm	114.3
Spare tyre	Size	T135/90D15 (High pressure) 205/65R15 94H*

NOTE

*: Optional items









SERVICE SPECIFICATIONS

31100030135

Items		Limit
Tread depth of tyre mm		1.6
Wheel runout (Radial runout) mm	Steel wheel	1.2 or less
	Aluminium wheel	1.0 or less
Wheel runout (Lateral runout) mm	Steel wheel	1.2 or less
	Aluminium wheel	1.0 or less

TROUBLESHOOTING

31100070205

Symptom		Probable cause		Remedy	Reference page
Rapid wear at shoulders	 <p>11X0109</p>	Under-inflation or lack of rotation	 <p>11X0116</p>	Adjust the tyre pressure.	31-4.
Rapid wear at centre	 <p>11X0110</p>	Over-inflation or lack of rotation	 <p>11X0117</p>		
Cracked treads	 <p>11X0111</p>	Under-inflation		Adjust the tyre pressure.	31-4.
Wear on one side	 <p>11X0112</p>	Excessive camber	 <p>11X0118</p>	Inspect the camber.	Refer to GROUP 33A - On-vehicle Service.
Feathered edge	 <p>11X0113</p>	Incorrect toe-in	 <p>11X0119</p>	Adjust the toe-in.	
Bald spots	 <p>11X0114</p>	Unbalanced wheel	 <p>11X0120</p>	Adjust the imbalanced wheels.	-
Scalloped wear	 <p>11X0115</p>	Lack of rotation of tyres or worn or out-of-alignment suspension		Rotate the tyres and check the front suspension alignment.	Refer to GROUP 33A - On-vehicle Service.

ON-VEHICLE SERVICE

31100090164

TYRE INFLATION PRESSURE CHECK**NOTE**

For information on tyre inflation pressure, refer to the label attached to the driver's side front door.

TYRE WEAR CHECK

31100100034


Measure the tread depth of tyres.

Limit: 1.6 mm

If the remaining tread depth is less than the limit, replace the tyre.

NOTE

When the tread depth of tyres is reduced to 1.6 mm or less, wear indicators will appear.

**WHEEL RUNOUT CHECK**

31100110037

Jack up the vehicle so that the wheels are clear of the floor. While slowly turning the wheel, measure wheel runout with a dial indicator.

Limit:

Item	Steel wheel	Aluminium wheel
Radial runout mm	1.2	1.0
Lateral runout mm	1.2	1.0

If wheel runout exceeds the limit, replace the wheel.

WHEEL AND TYRE

31100130071

INSTALLATION SERVICE POINT

Tighten the wheel nut to the specified torque.

Tightening torque: 98 Nm