



Audi A3 (8P) Airbag 9.41

From Ross-Tech Wiki

Contents

- 1 Coding
- 2 Adaptation
 - 2.1 ESP-Data (Powertrain)
- 3 Basic Setting
 - 3.1 Seat Occupied Recognition Control Module (J706)
- 4 Special Procedures
 - 4.1 Seat Occupied Recognition Control Module (J706): Reset

Coding

- **0?xxxxx: Battery Seperating**
 - 0 = not installed
 - 1 = installed (3.2l only)
- **0x?xxxx: Stages**
 - 3 = North America (USA/Canada)
 - 7 = Rest of World (RoW)
- **0xx?xxx: Options**
 - 0 = without Passenger Airbag Shut-Off (PR-4UE+9P0/9P1)
 - 0 = without Passenger Seat Occupation Detection (PR-4UB+9P1)
 - 1 = with Passenger Airbag Deactivation Key Switch with/without Belt Warning Driver Side (PR-4UF+9P0/9P1)
 - 2 = with Passenger Seat Occupation Detection and Airbag Disabled Warning Light (PR-4UB+9P5)
 - 3 = without Passenger Airbag Shut-Off and with Belt Warning Driver & Passenger Side (PR-4UE+9P3)
 - 4 = with Passenger Airbag Deactivation Key Switch and with Belt Warning Driver & Passenger Side (PR-4UF+9P3)
- **0xxx?xx: Side Airbags**
 - 1 = 2-Door: Front Side Airbags (PR-4X1)
 - 4 = 4-Door: Front Side Airbags (PR-4X1)
 - 5 = Front & Rear Side Airbags (PR-4X2)

- 6 = Front Side Airbags with Head Airbags (PR-4X3)
- 7 = Front & Rear Side Airbags with Head Airbags (PR-4X4)
- **0xxxx?x: Belt Inquiry**
 - 0 = North America (USA/Canada)
 - 0 = Rest of World (RoW) & 2-Door: without Belt Inquiry Driver's Side (PR-9P0)
 - 1 = Rest of World (RoW) & 2-Door: with Belt Inquiry Driver's Side (PR-9P1)
 - 1 = Rest of World (RoW) & 4-Door: with/without Belt Inquiry Driver's Side (PR-9P0/9P1)
 - 2 = Rest of World (RoW): Belt Inquiry Driver's & Passenger Side (PR-9P3)
- **0xxxxx?: Belt Tensioner**
 - 2 = Rest of World (RoW)
 - 5 = North America (USA/Canada)

Note: After replacing the contro module, make sure the ESP data is set too (see adaptation channel 050).

Adaptation

ESP-Data (Powertrain)

[Select]

[15 - Airbags]

[Adaptation - 10]

Channel 050

[Read]

- 1 = Front-Wheel-Drive (FWD)
- 2 = All-Wheel-Drive (AWD)

[Test]

[Save]

[Done, Go Back]

[Close Controller, Go Back - 06]

Basic Setting

Seat Occupied Recognition Control Module (J706)

If the Seat Occupied Recognition Control Module (J706) or the seat itself have been replaced, the basic setting has to be performed.

[Select]

[15 - Airbags]

[Security Access - 16]

Enter 30475, to enable the basic setting.

If you are having problems performing this security access, contact us (<http://www.ross-tech.com/contact.html>).

[Do it!]

[Basic Settings - 04]

Group 001

[Go!]

Activate the Basic Setting.

[ON/OFF/Next]

The reset has been performed.

[Done, Go Back]

[Close Controller, Go Back - 06]

Special Procedures

Seat Occupied Recognition Control Module (J706): Reset

If a repair on the Seat Occupied Recognition has been performed, a reset has to be performed too.

Prerequisites:

- Seat in normal position.
- Seat must NOT be occupied during the whole procedure.
- Seatbelt must NOT be plugged in.
- No faults in the system.
- Interior temperature must be between 0 °C and 37 °C (32 °F and 98 °F).

[Select]

[15 - Airbags]

[Security Access - 16]

Enter 30475, to enable the basic setting.

If you are having problems performing this security access, contact us (<http://www.ross-tech.com/contact.html>).

[Do it!]

[Adaptation - 10]

Channel 000

[Read]

[Save]

[Done, Go Back]

[Close Controller, Go Back - 06]

Retrieved from "[http://wiki.ross-tech.com/wiki/index.php/Audi_A3_\(8P\)_Airbag_9.41](http://wiki.ross-tech.com/wiki/index.php/Audi_A3_(8P)_Airbag_9.41)"

Unless otherwise noted, all content on this site is Copyright © 2000-2010 by Ross-Tech LLC. All rights reserved.

"VCDS" is a Registered Trademark of Ross-Tech, LLC.

Ross-Tech is not affiliated with the Volkswagen Group in any way.