

OBD-II Code Explanations for Codes from P0100 - P0199

P0200	Injector Circuit Malfunction
P0201	Injector Circuit Malfunction - Cylinder 1
P0202	Injector Circuit Malfunction - Cylinder 2
P0203	Injector Circuit Malfunction - Cylinder 3
P0204	Injector Circuit Malfunction - Cylinder 4
P0205	Injector Circuit Malfunction - Cylinder 5
P0206	Injector Circuit Malfunction - Cylinder 6
P0207	Injector Circuit Malfunction - Cylinder 7
P0208	Injector Circuit Malfunction - Cylinder 8
P0209	Injector Circuit Malfunction - Cylinder 9
P0210	Injector Circuit Malfunction - Cylinder 10
P0211	Injector Circuit Malfunction - Cylinder 11
P0212	Injector Circuit Malfunction - Cylinder 12
P0213	Cold Start Injector 1 Malfunction
P0214	Cold Start Injector 2 Malfunction
P0215	Engine Shutoff Solenoid Malfunction
P0216	Injection Timing Control Circuit Malfunction
P0217	Engine Overtemp Condition
P0218	Transmission Over Temperature Condition
P0219	Engine Overspeed Condition
P0220	Throttle/Pedal Position Sensor / Switch B Circuit Malfunction
P0220	ETS Throttle Position Sensor Property Malfunction (Hyundai)
P0221	Throttle/Pedal Position Sensor / Switch B Circuit Range / Performance Problem
P0222	Throttle/Pedal Position Sensor / Switch B Circuit Low Input
P0223	Throttle/Pedal Position Sensor / Switch B Circuit High Input
P0224	Throttle/Pedal Position Sensor / Switch B Circuit Intermittent
P0225	Throttle/Pedal Position Sensor / Switch C Circuit Malfunction
P0226	Throttle/Pedal Position Sensor / Switch C Circuit Range / Performance Problem
P0227	Throttle/Pedal Position Sensor / Switch C Circuit Low Input
P0228	Throttle/Pedal Position Sensor / Switch C Circuit High Input

Related Resources

- [OBD Code Database Index](#)

P0230	Fuel Pump Primary Circuit Malfunction
P0231	Fuel Pump Secondary Circuit Low
P0232	Fuel Pump Secondary Circuit High
P0233	Fuel Pump Secondary Circuit Intermittent
P0234	Engine Overboost Condition
P0235	Turbocharger Boost Sensor A Circuit Malfunction
P0236	Turbocharger Boost Sensor A Circuit Range / Performance
P0237	Turbocharger Boost Sensor A Circuit Low
P0238	Turbocharger Boost Sensor A Circuit High
P0239	Turbocharger Boost Sensor B Malfunction
P0240	Turbocharger Boost Sensor B Circuit Range / Performance
P0241	Turbocharger Boost Sensor B Circuit Low
P0242	Turbocharger Boost Sensor B Circuit High
P0243	Turbocharger Wastegate Solenoid A Malfunction
P0244	Turbocharger Wastegate Solenoid A Range / Performance
P0245	Turbocharger Wastegate Solenoid A Low
P0246	Turbocharger Wastegate Solenoid A High
P0247	Turbocharger Wastegate Solenoid B Malfunction
P0248	Turbocharger Wastegate Solenoid B Range / Performance
P0249	Turbocharger Wastegate Solenoid B Low
P0250	Turbocharger Wastegate Solenoid B High
P0251	Injection Pump Fuel Metering Control "A" Malfunction (Cam / Rotor / Injector)
P0252	Injection Pump Fuel Metering Control "A" Range / Performance (Cam / Rotor / Injector)
P0253	Injection Pump Fuel Metering Control "A" Low (Cam / Rotor / Injector)
P0254	Injection Pump Fuel Metering Control "A" High (Cam / Rotor / Injector)
P0255	Injection Pump Fuel Metering Control "A" Intermittent (Cam / Rotor / Injector)
P0256	Injection Pump Fuel Metering Control "B" Malfunction (Cam / Rotor / Injector)
P0257	Injection Pump Fuel Metering Control "B" Range / Performance (Cam / Rotor / Injector)
P0258	Injection Pump Fuel Metering Control "B" Low (Cam / Rotor / Injector)

P0259	Injection Pump Fuel Metering Control "B" High (Cam / Rotor / Injector)
P0260	Injection Pump Fuel Metering Control "B" Intermittent (Cam / Rotor / Injector)
P0261	Cylinder 1 Injector Circuit Low
P0262	Cylinder 1 Injector Circuit High
P0263	Cylinder 1 Contribution / Balance Fault
P0264	Cylinder 2 Injector Circuit Low
P0265	Cylinder 2 Injector Circuit High
P0266	Cylinder 2 Contribution / Balance Fault
P0267	Cylinder 3 Injector Circuit Low
P0268	Cylinder 3 Injector Circuit High
P0269	Cylinder 3 Contribution / Balance Fault
P0270	Cylinder 4 Injector Circuit Low
P0271	Cylinder 4 Injector Circuit High
P0272	Cylinder 4 Contribution / Balance Fault
P0273	Cylinder 5 Injector Circuit Low
P0274	Cylinder 5 Injector Circuit High
P0275	Cylinder 5 Contribution / Balance Fault
P0276	Cylinder 6 Injector Circuit Low
P0277	Cylinder 6 Injector Circuit High
P0278	Cylinder 6 Contribution / Balance Fault
P0279	Cylinder 7 Injector Circuit Low
P0280	Cylinder 7 Injector Circuit High
P0281	Cylinder 7 Contribution / Balance Fault
P0282	Cylinder 8 Injector Circuit Low
P0283	Cylinder 8 Injector Circuit High
P0284	Cylinder 8 Contribution / Balance Fault
P0285	Cylinder 9 Injector Circuit Low
P0286	Cylinder 9 Injector Circuit High
P0287	Cylinder 9 Contribution / Balance Fault
P0288	Cylinder 10 Injector Circuit Low
P0289	Cylinder 10 Injector Circuit High
P0290	Cylinder 10 Contribution / Balance Fault
P0291	Cylinder 11 Injector Circuit Low
P0292	Cylinder 11 Injector Circuit High
P0293	Cylinder 11 Contribution / Balance Fault
P0294	Cylinder 12 Injector Circuit Low
P0295	Cylinder 12 Injector Circuit High
P0296	Cylinder 12 Contribution / Range Fault

[Return to OBD Code Index](#)