



(A) CONNECTOR FOR VEHICLE SIDE WIRING

- 1 Not connected
- 2 Accelerator pedal sensor power supply
- 3 Accelerator pedal 2 sensor / air conditioning pressure switch power supply
- 4 Not connected
- 5 Air conditioning pressure switch
- 6 Not connected
- 7 Minimum oil pressure signal
- 8 Not connected
- 9 Not connected
- 10 Serial line K
- 11 Fiat CODE line
- 12 Key-on and ignition-controlled power supply (15/54)
- 13 Not connected
- 14 Fan 1 engagement request
- 15 Accelerator pedal 2 sensor / air conditioning pressure switch earth
- 16 Battery direct +12V
- 17 Cruise Control management (optional)
- 18 Not connected
- 19 Not connected
- 20 Two-way CAN line (LOW)