

Bluetooth Hands-Free preparation

Language setting

English, Spanish, and Canadian French are available. If the language setting is changed, all of the voice guidance and voice input commands are done in the selected language.

NOTE:

If the language setting is changed, phone registration is maintained. Phonebook records are not cleared, but each language has a separate phonebook. Therefore, entries created in one language will need to be re-entered in the phonebook of the new language.

Method 1

1. Activate Bluetooth Hands-Free.
2. Say: [Beep] "Setup".
3. Prompt: "Select one of the following:
Pairing options, confirmation prompts, select phone, language, or passcode, or say "cancel" to return to the main menu."
4. Say: [Beep] "Language".
5. Prompt: "Select a language: English, French, or Spanish."
6. Say: [Beep] "French" (Speak the desired language: "English", "French" or "Spanish").
7. Prompt: "French (Desired language) selected. Is this correct?"
8. Say: [Beep] "Yes".
9. Prompt: "French (Desired language) selected, returning to main menu" (Spoken in the newly selected language).

Method 2

1. Activate Bluetooth Hands-Free.
2. Say: [Beep] "French" (Say the desired language: "English", "French", or "Spanish").
3. Prompt: "Would you like to change the language to French (Desired language)?"
4. Say: [Beep] "Yes".
5. Prompt: "Please wait. Switching to French phonebook. French selected, returning to main menu" (Spoken in the newly selected language).

Mobile telephone programming (Pairing)

To use Bluetooth Hands-Free, the phone has to be programmed to the hands-free unit using the following procedure. Up to seven Bluetooth equipped mobile telephones can be programmed to your vehicle.

NOTE:

A mobile telephone can be programmed only when the vehicle is parked. Since the communication range of a Bluetooth equipped mobile telephone is about 10 meters (32 ft), if a mobile telephone is placed within a 10-meter (32 ft) radius of the vehicle, it may be detected/ programmed unintentionally while another telephone is being programmed.

1. Activate the Bluetooth application of the mobile telephone.

NOTE:

For the operation of the mobile telephone, refer to its instruction manual.

2. Activate Bluetooth Hands-Free.
3. Say: [Beep] "Setup".
4. Prompt: "Select one of the following: pairing options, confirmation prompts, select phone, language, or passcode, or say "cancel" to return to the main menu."

5. Say: [Beep] “Pairing options”.
6. Prompt: “Do you want to pair a phone, delete a phone, or list paired phones?”.
7. Say: [Beep] “Pair a phone”.
8. Prompt: “Please say a 4-digit pairing code.”.
9. Say: [Beep] “XXXX” (Speak an arbitrary 4-digit pairing code. This can be any combination of 4 numbers.).

NOTE:

Record the code as it will be used to program your phone in Step 16.

10. Prompt: “Pairing code XXXX (4- digit number). Is this correct?”.
11. Say: [Beep] “Yes” or “No”.
12. If “Yes”, go to Step 13 If “No”, the procedure returns to Step 8.
13. Prompt: “Start pairing procedure on phone. See phone's manual for instructions.”.
14. Using the mobile telephone, perform a search for the Bluetooth device (Peripheral device).

NOTE:

For the operation of the mobile telephone, refer to its instruction manual.

15. Select “Mazda” from the device list searched by the mobile phone.
16. Input the 4-digit pairing code set in Step 9 to the mobile telephone.
17. Prompt: “Please say the name of the phone after the beep.”.
18. Say: [Beep] “XXXX - - -” (Speak a “phone tag”, an arbitrary name for the phone.). Example: “Stan's phone.”

NOTE:

Speak a programmed “phone tag” within 10 seconds. If more than two mobile telephones are to be programmed, they cannot be programmed with the same or similar “phone tag”.

19. Prompt: “Adding XXXXXX - - - (Ex. “Stan's phone”) (Phone tag). Is this correct?”.
20. Say: [Beep] “Yes”.
21. Prompt: “Assign a priority for this phone between 1 and 7, where 1 is the phone used most often.”.
22. Say: [Beep] “1” (Speak a number of the desired priority from 1 to 7.).

NOTE:

Normally, “1” is to be input (Highest priority). If more than two mobile telephones are registered, input the priority order from 1 to 7.

23. Prompt: “XXXXXX - - - (Ex. “Stan's phone”) (Phone tag) set to priority X (Priority number). Is this correct?”.
24. Say: [Beep] “Yes”.
25. Prompt: “Pairing complete”. After a mobile telephone is registered, the system automatically identifies the phone. By activating Bluetooth Hands-Free again, or by activating Bluetooth Hands- Free first after turning the ignition switch from the LOCK to the ACC position, the system reads out a voice guidance, “XXXXXX - - - (Ex. “Stan's phone”) (Phone tag) is connected”. If two or more telephones are registered, the one with the highest priority is selected.

Making a call using a telephone number

1. Activate Bluetooth Hands-Free.
2. Say: [Beep] “Dial”.
3. Prompt: “Number, please”.
4. Say: [Beep] “XXXXXXXXXXXX (Ex. “555-1234”) (Telephone number)”.
5. Prompt: “Dialing XXXXXXXXXXXX (Ex. “555-1234”) (Telephone number) is this correct?”.
6. Say: [Beep] “Yes” or “No”.
7. When “Yes” is spoken, the procedure proceeds to Step 8. When “No” is spoken, the procedure returns to Step 3.
8. Prompt: “Dialing”.

Receiving an incoming call

1. Prompt: “Incoming call, press the pickup button to answer”.
2. To accept the call, press the pick-up button. To reject the call, press the hang-up button.

Hanging up a call

Press the hang-up button during the call. Beep will confirm that call is ended.

Volume adjustment

Turn the power/volume dial of the audio unit or navigation system to adjust the volume. Turn the power/volume dial to the right to increase volume, to the left to decrease it.

NOTE:
The volume can also be adjusted using the volume button on the steering wheel. The music volume of the audio unit and the navigation system cannot be adjusted while Bluetooth Hands-Free is being used. Voice guidance interrupt operation

Voice guidance can be stopped by pressing the talk button (Short press) while it is being heard. A new voice input command can then be spoken by the user. · Press the talk button (Short press).

Help function use

The help function informs the user of all the available voice commands under the current conditions.

1. Press the talk button (Short press).
2. Say: [Beep] “Help”.
3. Follow the prompts to receive the appropriate voice guidance instructions.